1. Download the "U-Prox Mobile ID" from App store.

U-Prox Mobile ID 4+
a2softin
Free

2. Open the U-Prox Mobile ID app, you will see below screen. Please select "Always Allow"

Allow "U-Prox ID" to access your location?

Location is required to detect nearby U-Prox controllers

Only While Using the App

Always Allow

Don't Allow

REQUEST

3. Press "REQUEST" & select Scan QR code

No key. Ask for it by Email or contact your administrator

REQUEST

No key. Ask for it by Email or contact your administrator

Scan QR code

Receive access by Desktop

Receive access via Email

Cancel

4. You will prompt to access the phone camera. Please press ok.

"U-Prox ID" Would Like to Access the Camera

Used Camera for QR scan

OK

Don't Allow

Scan QR code

Get QR from library

5. Now scan the QR code that given to you by your supplier. Make sure your phone have internet connection while you doing this.

6. The QR code only can be use once. Do not scan the QR code using any other QR code scanner. If not you have to purchase new credential ID (QR code).

7. You will see below screen if it successful. Press the setting icon & enable "By turning on the screen" option as shown on below images.

8. Your Bluetooth ID is ready to use on your phone.

9. To use the Bluetooth ID you just need to put your phone near the BLE reader & turn on your phone by pressing the on/off button on your phone.