OESD™

OESD Winter VILLAGE

FREESTANDING
Theatre

Fits hoop size 6" x 10" and larger

1
Design

THREAD LIST

Isacord Thread Colors

0015 White (2 spools)

* Project instructions included after design list.
Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

DESIGNS

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

*Fabric Required

12763-01 Front Wall FSA

Size Inches:	Size mm:	Stitch Count:
5.40 X 6.62 in.	**137.16 X 168.15 mm**	**61,696 St.**

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Lace 0015

OESD™

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

*Fabric Required

12763-02 Side Wall 1 FSA

Size Inches:	Size mm:	Stitch Count:
5.30 X 5.85 in.	134.62 X 148.59 mm	66,408 St.

1. Wall Placement Stitch.................................... 0015
2. Cut Line and Tackdown 0015
3. Posters Placement Stitch 0015
4. Cut Line and Tackdown 0015
5. Lace... 0015

*Fabric Required

12763-03 Side Wall 2 FSA

Size Inches:	Size mm:	Stitch Count:
5.30 X 5.85 in.	134.62 X 148.59 mm	66,148 St.

1. Wall Placement Stitch.................................... 0015
2. Cut Line and Tackdown 0015
3. Posters Placement Stitch 0015
4. Cut Line and Tackdown 0015
5. Lace... 0015

OESD™

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

*Fabric Required

12763-04 Back Wall FSA

Size Inches:	Size mm:	Stitch Count:
5.32 X 5.99 in.	**135.13 X 152.15 mm**	**55,993 St.**

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Lace... 0015

*Fabric Required

12763-05 Right Door FSA

Size Inches:	Size mm:	Stitch Count:
4.03 X 3.61 in.	**102.36 X 91.69 mm**	**30,175 St.**

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Lace... 0015

OESD™

*Fabric Required

12763-06 Left Door FSA

Size Inches:	Size mm:	Stitch Count:
4.03 X 3.61 in.	102.36 X 91.69 mm	30,008 St.

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Lace.. 0015

*Fabric Required

12763-07 Marquee FSA

Size Inches:	Size mm:	Stitch Count:
3.80 X 6.83 in.	96.52 X 173.48 mm	35,466 St.

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Lace.. 0015

DESIGNS

OESD™

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

*Fabric Required

12763-08 Blank Marquee FSA

Size Inches:	Size mm:	Stitch Count:
3.80 X 6.83 in.	**96.52 X 173.48 mm**	**35,050 St.**

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Lace... 0015

*Fabric Required

12763-09 Theatre Sign FSA

Size Inches:	Size mm:	Stitch Count:
4.98 X 5.74 in.	**126.49 X 145.80 mm**	**46,656 St.**

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Lace... 0015

OESD™

*Fabric Required

12763-10 Roof FSA

Size Inches:	Size mm:	Stitch Count:
5.67 X 5.94 in.	**144.02 X 150.88 mm**	**28,470 St.**

1. Right Side Roof Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Left Side Roof Placement Stitch.................... 0015
4. Cut Line and Tackdown 0015
5. Lace and Detail 0015

*Fabric Required

12763-11 Roof With Snow FSA

Size Inches:	Size mm:	Stitch Count:
5.66 X 5.94 in.	**143.76 X 150.88 mm**	**30,200 St.**

1. Right Side Roof Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Left Side Roof Placement Stitch.................... 0015
4. Cut Line and Tackdown 0015
5. Roof Snow Placement Stitch......................... 0015
6. Cut Line and Tackdown 0015
7. Lace and Detail 0015

*Fabric Required

12763-12 Foundation FSA

Size Inches:	Size mm:	Stitch Count:
5.44 X 5.97 in.	138.18 X 151.64 mm	17,316 St.

1. Placement Stitch 0015
2. Cut Line and Tackdown 0015
3. Detail and Cover Stitch................................. 0015

COLLECTION SUPPLIES

Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway

Fabrics/Textiles

- White cotton fabric 1/4 yard
- Note: Fabric sizes are estimates and may result in overage.

Notions & Tools

- OESD Alligator Clamps
- OESD Button Clips
- OESD Expert Embroidery Tape WashAway
- OESD Perfect Embroidery Press Cloth
- OESD Perfect Point and Press Tool
- Utility Knife
- Embroidery Needle Sharp 75/11

Isacord Thread Colors

- Per thread chart
- Match bobbin thread to top thread
- 0015 White (2 spools)
- 1252 Dark Tan (2 spools - color version)

OESD™

Completed Size: 7.5" H x 7" D x 5" W

12763-01
Requires 1 Design

12763-02
Requires 1 Design

12763-03
Requires 1 Design

12763-04
Requires 1 Design

12763-05
Requires 1 Design

12763-06
Requires 1 Design

12763-07
Requires 1 Design

12763-08
Requires 1 Design

or

12763-09
Requires 1 Design

12763-10
Requires 1 Design

12763-11
Requires 1 Design

or

12763-12
Requires 1 Design

EMBROIDERY

Notes

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

All designs are stitched with matching thread in the top and bobbin.

For other designs in the collection, use the applique templates as a guide to the dimensions of the various applique pieces.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

STEP 1

- Hoop one layer of AquaMesh and one layer of BadgeMaster for all designs.

STEP 2

- Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics to provide stiffness to the finished structure.
- Cut the prepared applique fabrics 1/4"-1/2" larger than the templates.

EMBROIDERY

OESD™

STEP 3

- Load selected design into the machine.
- Example design is Blank Marquee FSA (12763-08).
- Thread the machine per the thread chart.
- Tip: Before continuing to the next step, use machine lettering to add a name or message to fit within the blank marquee.
- Place hoop on the machine.
- Stitch Machine Step 1, Placement Stitch.

STEP 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Place the prepared applique fabric, right side up, completely covering the placement stitch.
- Tape in place to secure.

EMBROIDERY

STEP 5

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.

STEP 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible. If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will hold the applique in place.
- Tip: If the AquaMesh is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway.

STEP 7

- Return the hoop to the machine.
- Stitch Machine Step 3, Lace.
- Remember to match the bobbin thread to the upper thread colors.
- Note: If adding a name or message to fit within the marquee, do so before continuing to the next step.

ASSEMBLY

STEP 8

- When design is complete, remove the project from the hoop and trim the stabilizer 1/4"- 1/2" outside the design.
- Rinse each piece in warm running water until the design is only slightly sticky.
- Lay face down on a non-stick surface to dry. Parchment paper or a cooling rack work well. This prevents the piece from curling.
- Press each piece, right side down, on a Perfect Embroidery Press Cloth.

STEP 9

- Before assembly, take a utility knife and cut through all the layers of the tab entry on chosen marquee piece (12763-07 OR 12763-08.) Take care to not cut the satin stitching.

ASSEMBLY

STEP 10

- Assemble Right Door FSA (12763-05) and Left Door FSA (12763-06) by pulling the three flaps forward and attaching the two ceiling buttonettes into the corresponding eyelets on the side walls.

STEP 11

- Using alligator clamps attach Right Door FSA (12763-05) and Left Door FSA (12763-06) to the Front Wall FSA (12763-01) by pulling the ten buttonettes on the entryways to the front side of the Front Wall.

ASSEMBLY

STEP 12

- Attach the corresponding buttonettes on either Marquee FSA (12763-07) or Blank Marquee FSA (12763-08).

STEP 13

- Attach the marquee (12763-07 or 12763-08) eight buttonettes to the front wall (12763-01) eyelets.
- Note: Marquee should be placed with the tab entries facing up. The tab entries are used in attaching the theatre sign.

STEP 14

- Note: Movie posters should be placed toward the front wall.
- Attach the 4 buttonettes on the Front Wall FSA (12763-01) to the eyelets on the Side Wall 2 FSA (12763-03).
- Repeat this process for attaching the Front Wall FSA (12763-01) to the eyelets on the Side Wall 1 (12763-02).

STEP 15

- Attach the Foundation FSA (12763-12) with the fabric side face down by pulling the five buttonettes from the foundation to the corresponding eyelets on the front wall, doorways, and side walls.

STEP 16

- Attach the Roof FSA (12763-10 or 12763-11) to the Front Wall FSA (12763-01) by pulling the four buttonettes from the roof through the four corresponding eyelets on the front wall.

STEP 17

- Attach the Roof FSA (12763-10 or 12763-11) to the side walls (12763-02 & 12763-03) by pulling the six buttonettes on the roof through the six corresponding eyelets on the side walls.

STEP 18

- Attach Roof FSA (12763-10 or 12763-11) to Back Wall FSA (12763-04) by pulling the four buttonettes of the roof through the four corresponding eyelets on the back wall.
- Attach the Back Wall FSA (12763-04) to both side walls by pulling the eight buttonettes on the back wall to their corresponding eyelets on the side walls.
- Attach the Back Wall FSA (12763-04) to the Foundation FSA (12763-12) by pulling the remaining buttonette on the foundation to its corresponding eyelet.

STEP 19

- Shape the Theatre Sign FSA (12763-09) as pictured.

- Align the tabs at the base of the Theatre Sign FSA (12763-09) into the tab entries in the marquee while aligning the tabs in the front wall.
- Gently push down to secure.

FINISHING TOUCHES

- The theatre is complete. Enjoy.
- Add tea lights or pixie lights to create a glow.

ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.

TO SAVE PAPER

Only print the desired image by navigating to the image's page,
go to File > Print and select "Current page" in the print dialog
box. Repeat for each desired image.

OESD™

12763-01

12763-02

12763-03

12763-03

12763-02

12763-02

12763-03

APPLIQUE PATTERNS

OSD™

Print at 100%. No scaling. This box measures 1″ x 1″. Use the box as an accuracy guide when printing templates.

12763-04

Cut Out

12763-05

Cut Out

12763-06

12763-04

12763-07

12763-08

12763-09

O SD™

12763-10

12763-10

OESD™

Print at 100%. No scaling. This box measures 1″ x 1″. Use the box as an accuracy guide when printing templates.

12763-11

12763-11

12763-11

12763-11

APPLIQUE PATTERNS

O SD™

12763-12

Cut Out

MIRRORED PATTERNS

OESD™

Print at 100%. No scaling. This box measures 1″ x 1″. Use the box as an accuracy guide when printing templates.

12763-01

12763-02

12763-03

12763-03

12763-02

12763-02

12763-03

MIRRORED PATTERNS

OeSD™

Print at 100%. No scaling. This box measures 1″ x 1″. Use the box as an accuracy guide when printing templates.

12763-04

Cut Out

12763-06

Cut Out

12763-05

12763-04

12763-07

12763-08

12763-09

OESD™

Print at 100%. No scaling. This box measures 1″ x 1″. Use the box as an accuracy guide when printing templates.

12763-10

12763-10

MIRRORED PATTERNS

12763-11

12763-11

12763-11

12763-11

OᗺSD™

Print at 100%. No scaling. This box measures 1″ x 1″. Use the box as an accuracy guide when printing templates.

12763-12

Cut Out