Comsec Protection Systems

NC809DB / NC809DM
Mk4 Reset Point

Approved Document No: DNU8094100 Rev 3

RESET

Call

CE

RC S -V

RC connected to signal.
S signal.
–V common negative.

Reset points can be used to reset ceiling pulls and/or to remotely reset call points (see example configuration below right).

Several reset points can be connected in parallel on the same zone.

■ NC809DB Reset Points are button operated.

■ NC809DM Reset Points require an NC803M Magnetic Key.

EXAMPLE CONFIGURATION

signal

C | R | CP | CP

S | S or RC | S | S

-V | -V | -V | -V

TO PANEL

common negative

KEY TO DIAGRAM: **R** = Reset Point; **CP** = Ceiling Pull; **C** = Standard Call Point