# TWS Wireless EarBuds

Model: URBAN

## User Manual

## Overview

**Chose eartips**




Medium size Eartips are the best fit for most people. It is also recommended for first-time users.

## How to pair

**First use**



Take out both 2 earbuds then re-insert them back into the case to activate the earphones.
Notes: If Earbuds fail to be charged, please charge the case via USB cable(for details, please refer the following step)

### How to pair

1. Activating the EarBuds.
2. Take out the EarBuds from the case, they will auto power on and pair with each other.
3. Left EarBud will auto enter into pairing mode while LED light on right EarBud will be turned off.
4. Search for "CB-URBAN"on mobile devices and tap to pair it to both EarBuds.

## Resetting

**Please try the following steps if fail to connect with the mobile device.**



1. Take out the two earbuds, long press it for 3 secs until the LED lights are turned off.
2. Press the button for 10s, the LED lights will be on in red and white at the same time, then the lights will turn off.
3. Put the two earbuds back into the charging case again, then take out from the case, it will auto turn on and pair with each other.
4. Search for "CB-URBAN" on the mobile devices and connect it with the earbuds.

### Wearing

Insert the Earbuds into your ears gently with the mic facing towards the front side.

## Charging

**a Charging the Earbuds**



Insert the EarBuds into the charging case (pogo pins should be well-connected)
LED light will be Red while charging and turns into White( will be last for 60s) once full charged.

**b Charging the Case**




Note: There are 4 LED lights to show the charging case battery status, its means there is 25%, 50%, 75%, 100% battery in sequence.

## Functions

**Power-On**

Method 1: Take out the EarBuds from the charging case, it will auto power on.
Method 2: Tap the multi-function buttons for 1s

**Power-Off**

Method 1: Put the EarBuds back into the charging case, it will auto power off.
Method 2: Tap the multi-function buttons for 3s

**Answer/Hang up the call**

Tap the multi-function button to answer the call, Tap the button again to hang up.

**Decline a call**

Tap the multi-function button for 1s.

**Switch Audio Output**

Under the calling status, Tap the multi-function button for 1s to switch audio output between cellphone and Earbuds.

**Mute-on/off**

Under the calling status, Tap the multi-function button twice to turn on or off the Mute function.

**Play/Pause the music**

Tap the multi-function button to play pause the music.

**Skip to last song**

Press the left 2 Times for last song.

**Skip to next song**

Press the right 2 Times for next song.

**Volume increase**

Press the right button 3 Times to increase the volume

**Volume decrease**

Press the left button 3 Times to decrease the volume

**Voice Assistant**

Under the standby status, tap the multi-function button for 2s to spelling error the voice assistant (eg. Siri).

**Re-dial the last calling number**

Under the stand by status,tap MFB 4times,it will dial the last calling number.

Model: URBAN
Transmission Distance: 15 meters
Bluetooth Vision: V5.0
Charging Time: 1 hour
Talking Time: 8 hours
Battery type: li-ion
Mode: HFP、HSP、H2DP、AVRCP
Battery capacity: 50mAh
Charging Case capacity: 550mAh
Charging case input: DC 5V/400mAh
Charging case output: DC 5V /40mAh

## Tips

1. Before using it, please read the user manual carefully and keep it for reference in the future.
2. Charge the product fully before the first use.
3. If the product has not been used for more than a month, kindly charge it fully before charging it.
4. Kindly use the qualified adapter.
5. If it can not be found by your mobile devices, please check whether it is in a pairing mode. If not paired with mobile devices for a long time, it will automatically exit pairing mode, in such cases please re-enter the pairing mode. If a procedure error occurs on mobile devices, please reset it, otherwise, try resetting the earbuds.

## Warning

1. Never disassemble or modify it to avoid causing any damages or dangers.
2. Do not store it in extreme temperatures (under 0℃ or over 45℃)
3. Keep it away from the kids.
4. Do not use it during thunderstorms.
5. Do not use harsh chemicals or strong detergents to clean it.
6. Keep it dry.

FC CE RoHS