LYCAN®
GAMING
## REMUS

4-IN-1
GAMING COMBO

Model: LGCOMBO4

USER MANUAL

KEYBOARD FEATURES

- 104 Keys including 12 Multimedia Buttons
- Rainbow LED Backlight
- Palm Rest
- 1.5m USB Cable
- Plug & Play

KEYBOARD SPECIFICATIONS

- Current max: 100mA
- Compatible with Windows XP, Vista or Windows 7, Windows 8, Windows 10

HEADSET FEATURES

- 50mm Drivers
- Flip Up Microphone
- In-Line Controls
- Blue LED Backlight
- Dual Connection: 3.5mm & USB
- 2.1m Cable

HEADSET SPECIFICATIONS

- Headset Sensitivity: 100dB ± 3dB
- Headset Frequency Response: 20Hz - 20kHz
- Microphone Sensitivity: -42dB ± 3dB
- Microphone Frequency Response: 100Hz - 10kHz

MOUSE FEATURES

- Ergonomic Design
- Adjustable DPI up to 3,600
- 4 Buttons
- Rainbow LED Backlight
- 1.5m USB Cable
- Plug & Play

MOUSE SPECIFICATIONS

- Resolution: 1,200 / 1,800 / 2,400 / 3,600 DPI
- Compatible with Windows XP, Vista or Windows 7, Windows 8, Windows 10

MOUSE PAD FEATURES

- RGB Lighting
- Smooth Tracking Surface
- Anti-slip Base
- Plug & Play

MOUSE PAD SPECIFICATIONS

- 7 RGB Colours
- 14 Lighting Modes
- Surface Material: Microfiber
- Detachable 1.8m USB Charging Cable
- Input: DC 5V/100mA

CONNECTION - KEYBOARD & MOUSE

① Connect USB plug of keyboard and mouse to USB ports on your desktop computer or laptop.

USB   USB

② LED on keyboard and mouse will illuminate once it is connected and ready to use.

CONNECTION - HEADSET

① Connect 3.5mm plug of headset to 3.5mm port on your desktop computer or laptop.

② Connect USB plug of headset to USB ports on your desktop computer or laptop. The LED on headset will illuminate once it is connected and ready to use.

3.5mm

USB   USB   3.5mm

RGB LIGHTING ON MOUSE PAD

①　Connect Micro USB plug into top left-hand corner of mouse pad.

Micro USB

②　Connect USB-A Plug into USB port on your desktop computer or laptop.

USB　USB

③　Press the power button 🔆 to switch RGB lighting ON/OFF.

④　You can also press this same button to cycle through the RGB lighting modes.

KEYBOARD RAINBOW LED BACKLIGHT

Turn LED Backlight ON/OFF

FN + Page Up + — Increase LED Brightness

FN + Page Down — — Decrease LED Brightness

KEYBOARD MULTIMEDIA KEYS

FN + F1 — Open Media Player

FN + F2 — Decrease Volume

FN + F3 — Increase Volume

FN + F4 — Mute Audio

FN + F5 — Stop Media

FN + F6 — Back

FN + F7 — Play / Pause

FN + F8 — Forward

FN + F9 — Mail

FN + F10 — Web Home

FN + F11 — Lock Keyboard

FN + F12 — Calculator

WARNING

- Keep combo accessories away from water and moisture to avoid any damage to hardware.
- Keep combo accessories away from direct sunlight to avoid colour fading.
- Regularly wipe dust from keyboard with dry cloth to extend keystroke lifespan.

BRED FOR GAMING

www.lycangamer.com

v3