| | | |
|---|---|---|
| 13" - 35" | Load 0-12kgs/0-26.4lbs | VESA 75x75, 100x100 |
| Tilt +90°/-85° | Swivel 180° | Rotate 360° |

Installation *INSTRUCTIONS*

**VM-GE61 US3.0**

## Warning

⚠ Prior to the installation of this product, the installation instruction must be read and completely understood. Failure to do so may result in personal injury, property damage or voiding of factory warranty.

⚠ Do not install on a structure that is prone to vibration, movement or chance of impact. Reinforce the structure as required before installation.
Make sure that the edge of table top is load-bearing enough.

⚠ The desk clamp can support a maximum thickness of 8.5 cm. Confirm the desk edge before installation.

⚠ Pay attention to the weight capacity of the mount. Exceeding the limitation can result in function unworkable or even serious personal injury and property damage.

⚠ Never operate the mount if parts are missing or damaged. Please contact our customer service team.

## PRODUCT LINE GRAPH

Organize cables using the clips in the upper arms.

Pull the lower cover out as shown, run cables through the lower arms and reattach the covers.

## Left Panel

**Falls Down**

**Problem :**
After being attached to the arm, the monitor falls down and can not stay at the desired height by itself.

**Solution :**

Turn counter-clockwise("+" direction) to increase gas spring tension until the monitor can stay at the desired height by itself.

**Rises up**

**Problem :**
After being attached to the arm, the monitor rises up and can not stay at the desired height by itself.

**Solution :**

Turn clockwise("-" direction) to reduce gas spring tension until the monitor can stay at the desired height by itself.

## Step 6: Tilt & Swivel Adjustment

VESA Swivel Adjustment
**S=5mm**
- +

VESA Tilt Adjustment
**S=5mm**
- +

**S=5mm**
**D**

Please do not move stand outside desk for safety !

Desktop ✓

Desktop ✗

**Desk**

Use a 5mm hex wrench to adjust the damp for Tilt and Swivel. Turn counter-clockwise to reduce damping and clockwise to increase damping.

## TOOLS REQUIRED NOT INCLUDED

## PARTS INCLUDED

| A | M4x12 (x4) | M4x30 (x4) | 12X5.8X16 (x4) |
|---|---|---|---|
| B | S=3mm (x1) | S=4mm (x1) | |
| C | M4x10 (x1) | D | S=5mm (x1) |

a (x1)
Base

b (x1)
VESA Plate

c (x1)
Gas Spring Arm

d (x1)
Lower Arm

**Option A**:
**Clamp Installation.**
**After this step,then Step 2 on Page 6.**



**Desk**

1.5-8.5 cm
0.6-3.35 in

Adjust the Clamp width to fit with desk. Secure stand to desktop by tightening Clamp.

M4x10

C

**NOTE:** Hand tighten screws to avoid over tightening.

Slide the monitor onto the head of swivel arm, install the security bolt (C). Make sure the security bolt is installed before you rotate the monitor.

S=5mm

D

S=5mm

Press down the arm to a horizontal position

Be sure to keep the arm in horizontal position during adjustment. Or else, it would be difficult to adjust the mount.

For proper functioning of this mount, depending on different weight of monitor you might need to adjust tension in the gas spring arm using 5 mm allen key (D).

**OPTION A:**
**For Flat Back Monitor**

M4x12

A

TOP OF Monitor

**NOTE:** Hand tighten screws to avoid over tightening.

Flat surface installation:Install 4 short screws through faceplate to monitor via mounting holes.Do not tighten the screws excessively or your monitor might be damaged.

**OPTION B:**
**For Recessed/Curved Back Monitor**

M4x30

A

12X5.8X16

A

TOP OF Monitor

**NOTE:** Hand tighten screws to avoid over tightening.

Recessed surface installation:Put 4 spacers between faceplate and monitor.Install 4 long screws through faceplate,spacers to monitor via mounting holes.Do not tighten the screws excessively or your monitor might be damaged.

**Option B:**
**Grommet Base Installation**

S=5mm

D

Ⅰ

S=5mm

Remove the Two screws from the base by the short-head 5mm Allen key(D).

Ⅱ

S=4mm

B

**Part 1**

S=4mm

Remove the Four screws from the base by the short-head 4mm Allen key(B). Get Part 1 for using to step Ⅴ.

**S=3mm**
**B**

**Desk**

**S=3mm**

DO NOT tighten the screw
excessively or it might be stripped.

**Note:** Please note that the
side with the label" Base " 
is installed on the base(a)
when installing the lower
arm(d) to the base (a).

Install the lower arm (d) to the base (a).
Secure the arm by tightening the inside screw using 3mm Allen key (B).



**S=3mm**
**B**

**S=3mm**

**Desk**

DO NOT tighten the screw
excessively or it might be stripped.

Insert the gas spring arm (C) above the lower arm and fasten the screw
in the front.