Setting up you new Leitner headset with your phone or computer is a piece of cake! (Cake not included.)

1) Plug your Leitner Corded Headset into the Quick Disconnect Cord (sold separately). The ends should snap together

2) Plug the Quick Disconnect Cord into your phone or computer

3) Use a pen to adjust the compatibility setting switches on your Leitner headset cord until you get clear 2-way sound. Check out the photo to the right. Want to get the right compatibility setting for your particular phone or computer without having to test all four options? Just give us a call at 1-800-432-3738 ☺

Use a pen to adjust these two switches until you get the best sound for your phone. Or, just call us at 1-800-432-3738 and we'll tell you the right setting.

Want more help? Call 1-800-432-3738 Mon-Fri 9:00-7:30 Eastern Time for free support!