CONTENTS PAGE

2 - Parts List
3 - Launch ramp
11 - Launch spine
14 - Linking with funbox
17 - Linking with grind rail
21 - Folding and transporting

PARTS LIST

1 - Bottom panel
1 - Top panel
1 - Toe piece
2 - Legs
2 - Rubber feet
3 - 3” bolts
8 - 2” bolts
6 - Small washers
18 - Big washers
11 - Lock nuts
2 - J-bolts
2 - Wing nuts
2 - Knobs

LAUNCH RAMP INSTRUCTIONS



ATTACHING PANELS

STEP 1

Align the two panels with the hinges together

Align the panels so the edges of panels are flush with each other



ATTACHING PANELS

STEP 2

Bolt together the panels using the 3″ bolts provided on the 3 hinges

Place a small washer on the 3″ bolt and insert it through both hinges

Follow it with a small washer and a lock nut to tighten the hinges together

Caution:

Do not tighten the bolts too tight to allow the hinges to freely move



TOE PIECE

STEP 3

Place the toe piece on the bottom panel with only 3 hinges

Align the 4 holes in the coping with the 4 holes in the tubing of the panel



TOE PIECE

STEP 4

Use the 2″ bolts to attach the toe piece to the launch ramp

Place a big washer onto the 2″ bolt and insert it through the toe piece and tubing

Follow it with a big washer and a lock nut to tighten the toe piece to the launch ramp





COPING

STEP 5

Place the coping on top panel of the launch ramp with the receivers

Align the 4 holes in the coping with the 4 holes in the tubing of the panel



COPING

STEP 6

Use the 2″ bolts to attach the coping to the launch ramp

Place a big washer onto the 2″ bolt and insert it through the tubing and coping

Follow it with a big washer and a lock nut to tighten the coping to the launch ramp



INSERTING LEGS

STEP 7

Insert the legs into receivers matching the angle of the legs with the ramp

STEP 8

Tighten the legs down with the two knobs by screwing them into the threads of the receivers

STEP 7



STEP 8



LAUNCH SPINE



ALIGNING RAMPS

STEP 1

Align the two launch ramps facing each other as shown

Bring them together so the hinges on each side meet

Align the hinges so the sides of the ramp are flush with each other



BOLTING RAMPS

STEP 2

Bolt the ramps together using J-bolts on both hinges

Place a big washer on a J-bolt and slide it through both hinges and use a wing nut on the other side to tighten the ramps together



LINKING FUNBOX WITH LAUNCH RAMP



ALIGNING RAMPS

STEP 1

Align the two ramps together so the hinges are facing each other

Bring them together so the hinges on each side meet

Align the hinges so the sides of the ramp are flush with each other

Place the coping of the launch ramp onto the coping of the funbox or align the launch ramps coping so it is flush with the top of the funbox



BOLTING RAMPS

STEP 2

Bolt the ramps together using J-bolts on both hinges

Place a big washer on a J-bolt and slide it through both hinges and use a wing nut on the other side to tighten the ramps together



LINKING GRIND RAIL WITH LAUNCH RAMP



ATTATCHING HINGE

STEP 1

Take an end cap off of each grind rail to expose the holes

Step 2

Insert the hinge into one of the grind rails

Align the first 2 holes in the hinge with the first 2 holes in the rail

STEP 1



STEP 2



BOLTING HINGE

STEP 3

Bolt the hinge onto the rail at the first two holes with the washers and bolts provided

Place a washer on each bolt and screw each one into the threads of the hinge



ALIGNING PIECES

STEP 4

Align the hinges together so the holes meet each other

Attach the grind rail to any hinge on the launch ramp

STEP 5

Place a big washer on a J-bolt and slide it through both hinges and follow it with a wing nut on the other side to tighten it to the launch ramp

STEP 4



STEP 5



Folding FRESHPARK Ramps

Step 1:
Lay the ramp onto its side (team of 2 recommended)





Folding FRESHPARK Ramps

Step 2:
Remove all support bars and legs and carefully fold the panels



Step 3:
Fold into a desire configuration for easy storage





Warning
When transporting, never carry or push the ramp by yourself



Caution: To reduce the risk of injuries to hands and fingers, never insert your hands or fingers in between the panels or any folding joints.