AJAZZ × NACODEX®

本安装手册适用于澳门AJAZZ和澳门NACODEX品牌产品具体有各种键盘指示灯和、模式切换等特定安装步骤和操作说明，请参阅本安装手册获取更多信息。
产品咨询请登陆：www.ajazz.com

AK992蓝牙三模机械键盘

BT Three Modes mechanical keyboard

安装说明书

User Manual

简体中文版

一、产品规格

产品名称 **AJAZZ 992**

产品型号 AK992

键盘结构 三模蓝牙机械键盘

键帽材质 ABS+PBT双色工艺

产品尺寸 **Inches** 18.5x5.5x1.7

产品重量 **Inches** 1.8kg

电池 锂电池 3000mAh（无线版）1200mAh

充电时间 约3小时

键轴结构 PBT DEW

按键寿命 1.5M

灯光效果 RGB LED灯珠 **Inches** 2.5W/灯珠

灯光模式 **Inches** 21种

连接方式 蓝牙、无线、有线

适用系统 Windows Vista /7/8/10/11, MAC, Android

二、产品安装说明

1. 三模连接说明

开关长键（图1）

左侧的开关长键位于键盘的背面，用以切换模式。

“**|||**”：三模模式；

“**||**”：蓝牙模式；

“**|**”：无线模式；

指示灯（红色为有线/蓝色为蓝牙/绿色为无线）

1. 指示灯 “**|||**”：Num开关；
2. 指示灯 “**||**”：Caps开关；
3. 指示灯 “**|**”：Scroll开关；
4. 指示灯 “**||**”：蓝牙模式；
5. 指示灯 “**|**”：无线模式；

（一）键盘上方的键盘，有有线/无线/蓝牙三种模式切换，先需要将键盘的开关长键（图1）中的三种模式开关键位置调整好，再按下键盘上方的三种模式切换键来进行切换。

使用步骤

1. 安装好电池；
2. 按照说明书调整开关键位置；
3. 按下键盘上方的模式切换键，等待指示灯闪烁；
4. 在蓝牙设置中搜索设备，并连接键盘；
5. 连接成功后，即可开始使用键盘。

有线模式

1. 将USB-C数据线插入键盘背面的USB-C接口；
2. 将USB-A端插入电脑USB接口；
3. 键盘会自动进入有线模式，并一有线指示灯闪烁。

无线模式

1. 将2.4G无线接收器插入电脑USB接口；
2. 按住键盘上方的无线模式切换键，等待指示灯闪烁；
3. 在设备管理器中搜索并连接无线设备；
4. 连接成功后，即可开始使用键盘。

蓝牙模式

1. 按住键盘上方的蓝牙模式切换键，等待指示灯闪烁；
2. 在蓝牙设置中搜索并连接键盘；
3. 连接成功后，即可开始使用键盘。

2. 多媒体功能说明

Fn+F1 计算器功能

Fn+F2 我的电脑

Fn+F3 浏览器

Fn+F4 静音

Fn+F5 音量减

Fn+F6 音量增

Fn+F7 上一曲

Fn+F8 暂停/播放

Fn+F9 下一曲

Fn+F10 静音

Fn+F11 音量减

Fn+F12 音量增

3. 三模连接说明

1. 蓝牙模式连接说明

蓝牙长键（Fn+左Win）

蓝牙长键 AK992.5.0-2.0版键盘/**AK992.5.0-2.0版键盘**/**AK992.5.0-3.0版键盘**：

（1）键盘处于关机状态，按住蓝牙长键（Fn+左Win）3秒，键盘蓝牙灯闪烁，进入蓝牙配对模式；

（2）键盘处于开机状态，按住蓝牙长键（Fn+左Win）3秒，键盘蓝牙灯闪烁，进入蓝牙配对模式；

2.2.4G模式连接 Fn+R

长按Fn+R进入2.4G模式，闪烁灯亮，表示进入2.4G模式，可以通过长按Fn+R来切换蓝牙、2.4G模式。

3. 有线模式连接

开启键盘后，可通过数据线连接电脑，即可进行有线模式。

四、灯效模式说明

灯光模式切换 Fn+F

按Fn+F键，可切换灯光模式，共21种。

灯光亮度 Fn+L

按Fn+L键，可调整灯光亮度，共5级。

灯光速度 Fn+P

按Fn+P键，可调整灯光速度，共5级。

灯光颜色 Fn+C

按Fn+C键，可调整灯光颜色，共8种。

灯光方向 Fn+V

按Fn+V键，可调整灯光方向，共2种。

灯光关闭 Fn+Del

按Fn+Del键，可关闭灯光，再按一次恢复灯光。

五、多媒体功能说明

Fn+F1 计算器功能

Fn+F2 我的电脑

Fn+F3 浏览器

Fn+F4 静音

Fn+F5 音量减

Fn+F6 音量增

Fn+F7 上一曲

Fn+F8 暂停/播放

Fn+F9 下一曲

Fn+F10 静音

Fn+F11 音量减

Fn+F12 音量增

六、灯光设置

1. 灯光模式切换

灯光模式切换 Fn+F

按Fn+F键，可切换灯光模式，共21种。

灯光亮度 Fn+L

按Fn+L键，可调整灯光亮度，共5级。

灯光速度 Fn+P

按Fn+P键，可调整灯光速度，共5级。

灯光颜色 Fn+C

按Fn+C键，可调整灯光颜色，共8种。

灯光方向 Fn+V

按Fn+V键，可调整灯光方向，共2种。

灯光关闭 Fn+Del

按Fn+Del键，可关闭灯光，再按一次恢复灯光。

七、灯光设置

1. 灯光模式切换

灯光模式切换 Fn+F

按Fn+F键，可切换灯光模式，共21种。

灯光亮度 Fn+L

按Fn+L键，可调整灯光亮度，共5级。

灯光速度 Fn+P

按Fn+P键，可调整灯光速度，共5级。

灯光颜色 Fn+C

按Fn+C键，可调整灯光颜色，共8种。

灯光方向 Fn+V

按Fn+V键，可调整灯光方向，共2种。

灯光关闭 Fn+Del

按Fn+Del键，可关闭灯光，再按一次恢复灯光。

八、热插拔操作步骤说明

热插拔：可直接不用焊接，将轴体插入键盘的轴座即可完成安装，以及拆轴装更换大师所说明操作。

（1）拆开键盘外壳

（2）拆下键盘PCB板

（3）拆下键盘轴体

（4）安装轴体

（5）安装键盘PCB板

（6）安装键盘外壳

（7）安装键盘键帽

（8）安装键盘支架

（9）安装键盘支架

（10）安装键盘支架

（11）安装键盘支架

（12）安装键盘支架

（13）安装键盘支架

（14）安装键盘支架

（15）安装键盘支架

Thank you very much for purchasing our AJAZZ AK992. It has various cool functions and lighting effects. I hope it can bring you a new operating experience. Driver download: http://www.a-jazz.com/

English Version

2. Description of the switch indicator light

Switch Function (Figure 1)

The three-speed toggle switch series 2.4G/USB/Bluetooth mode, and the default USB mode.

“**|||**” : Wired mode;

“**||**” : Bluetooth mode.

“**|**” : Wireless mode.

Indicator light: the top left of the keyboard is white light (picture 2)

1. Indicator “**|||**” : Num switch;
2. Indicator “**||**” : Caps switch;
3. Indicator “**|**” : 2.4G mode;
4. Indicator “**||**” : Bluetooth mode;
5. Pin key : If the indicator is on the power, the charging red light fn is always red, and the system is fully charged (connect the USB cable to any wireless mode to charge the device).

Keyboard Function: Keyboard power is low, the Pin key backlight is red The light blinks continuously to indicate charging.

Scroll Wheel Function

① Volume adjustment function:

Turn the knob to the left: volume -

Turn the knob to the right: volume +

② Mute: Press to mute, then press to restore.

Note: By default, the volume adjustment will follow the computer, and the computer volume will jump 2 bars after turning one bar.

Sleep Mode

Power-Saving Sleep : The backlight turns off after 5 minutes of no key operation on the keyboard, press any button to wake up the backlight of the keyboard and reconnect to Bluetooth (1.4).

Deep Sleep: Deep standby after 30 minutes of no key operation on the keyboard, Bluetooth (1.4) is disconnected and sleeps, press any button to wake up the keyboard backlight and reconnect to Bluetooth (1.4).

(Figure1)

(Figure2)

3. Mode Connection Description

1. Bluetooth Mode Connection: Fn+Q / W / E

Bluetooth connection: Fn+Q / W / E (corresponding to channel Q), AK992.5.0-2.0(corresponding to channel W), AK992.5.0-3 (corresponding to channel E).

① Long press the Fn+Q or W or E key combination for 3 seconds to pair, the Q key light (blue light) flashes quickly to enter the pairing mode, and the Bluetooth device (Bluetooth 5.1 or above) can be paired and connected to the keyboard.

② Short press the Fn+Q/W/E key combination to switch the Bluetooth channel, the light of the paired Q/W/E key flashes slowly, the connection is successful, and the light returns to normal light effect.

2. 2.4G Wireless Connection: Fn+R

Long press Fn+R to enter 2.4G strong code pairing, the R button light (green light) flashes quickly to enter the code pairing mode, and the receiver is paired with the device. The code is successfully paired. (It has been paired before leaving the factory, and the number key is 1 to 6 drive the percentage of power).

3. Wired Mode Connection

Toggle the switch to the “**|**” position, which is the wired mode.

4. Backlight Mode

Fn+L Lighting effect switching, 21 kinds of lighting effects cycle in turn

Fn+L (1), (2): 24 non-customizable three groups of game lighting effects (preset all white light)

Fn+L(1) : Default FPS mode : W / A / S / D / ↑ / ← / →

Fn+L(2) : Default MOBA mode : Q / W / E / R / A / S / D / F / 1 / 2 / 3 / 4 / 5 / M

Fn+L(3) : Default LT key office mode: K / J / B (English letters) / ↑ / ← / ↓ / → / Tab / Space / 4 / 5 / M

Fn+ : Discard: Save the lighting mode for the lighting effects of the above three game modes, press the button once during the lighting effect of the above three game modes to discard the current lighting effect.

Fn+ ↑ : Light brightness - (five gears) adjusted to the highest backlight indicator flashes 3 times to indicate

Fn+ ↓ : Light brightness - (five levels) adjusted to the lowest backlight indicator flashes 3 times to indicate

Fn+ ← : Dynamic lighting direction switching

Fn+ → : Switch backlight color

Fn+ ← : Light speed - (five gears) adjusted to the lowest backlight indicator flashes 3 times to indicate

Fn+ → : Light speed - (five gears) adjusted to the lowest backlight indicator flashes 3 times to indicate

Single Light Version

2. Description of the switch indicator light

Switch Function (Figure 1)

The three-speed toggle switch series 2.4G/USB/Bluetooth mode, and the default USB mode.

“**|||**” : Wired mode;

“**||**” : Bluetooth mode.

“**|**” : Wireless mode.

Indicator light: the top left of the keyboard is white light (picture 2)

1. Indicator “**|||**” : Num switch;
2. Indicator “**||**” : Caps switch;
3. Indicator “**|**” : 2.4G mode;
4. Indicator “**||**” : Bluetooth mode;
5. Pin key : If the indicator is on the power, the charging white light fn is always red, and the system is fully charged (connect the USB cable to any wireless mode to charge the device).

Keyboard Function: Keyboard power is low, the Pin key backlight is white The light blinks continuously to indicate charging.

Scroll Wheel Function

① Volume adjustment function:

Turn the knob to the left: volume -

Turn the knob to the right: volume +

② Mute: Press to mute, then press to restore.

Note: By default, the volume adjustment will follow the computer, and the computer volume will jump 2 bars after turning one bar.

Sleep Mode

Power-Saving Sleep : The backlight turns off after 5 minutes of no key operation on the keyboard, press any button to wake up the backlight of the keyboard and reconnect to Bluetooth (1.4).

Deep Sleep: Deep standby after 30 minutes of no key operation on the keyboard, Bluetooth (1.4) is disconnected and sleeps, press any button to wake up the keyboard backlight and reconnect to Bluetooth (1.4).

(Figure1)

(Figure2)

3. Combination Key Function Description

1. Bluetooth Mode Connection: Fn+Q / W / E

Bluetooth connection: Fn+Q / W / E (corresponding to channel Q), AK992.5.0-2.0(corresponding to channel W), AK992.5.0-3 (corresponding to channel E).

① Long press the Fn+Q or W or E key combination for 3 seconds to pair, the Q key light (blue light) flashes quickly to enter the pairing mode, and the Bluetooth device (Bluetooth 5.1 or above) can be paired and connected to the keyboard.

② Short press the Fn+Q/W/E key combination to switch the Bluetooth channel, the light of the paired Q/W/E key flashes slowly, the connection is successful, and the light returns to normal light effect.

2. 2.4G Wireless Connection: Fn+R

Long press Fn+R to enter 2.4G strong code pairing, the R button light (green light) flashes quickly to enter the code pairing mode, and the receiver is paired with the device. The code is successfully paired. (It has been paired before leaving the factory, and the number key is 1 to 6 drive the percentage of power).

3. Wired Mode Connection:

Toggle the switch to the “**|**” position, which is the wired mode.

4. Backlight Mode

Fn+L Lighting effect switching, 21 kinds of lighting effects cycle in turn

Fn+L (1), (2): 24 non-customizable three groups of game lighting effects (preset all white light)

Fn+L(1) : Default FPS mode : W / A / S / D / ↑ / ← / →

Fn+L(2) : Default LOL mode : Q / W / E / R / A / S / D / F / 1 / 2 / 3 / 4 / 5 / M

Fn+L(3) : Default LT key office mode: K / J / B (English letters) / ↑ / ← / ↓ / → / Tab / Space / 4 / 5 / M

Fn+ : Discard: Save the lighting mode for the lighting effects of the above three game modes, press the button once during the lighting effect of the above three game modes to discard the current lighting effect.

Fn+ ↑ : Light brightness - (five gears) adjusted to the highest backlight indicator flashes 3 times to indicate

Fn+ ↓ : Light brightness - (five levels) adjusted to the lowest backlight indicator flashes 3 times to indicate

Fn+ ← : Dynamic lighting direction switching

Fn+ → : Switch backlight color

Fn+ ← : Light speed - (five gears) adjusted to the lowest backlight indicator flashes 3 times to indicate

Fn+ → : Light speed - (five gears) adjusted to the lowest backlight indicator flashes 3 times to indicate

3. Mode Connection Description

1. Bluetooth Mode Connection: Fn+Q / W / E

Bluetooth connection: Fn+Q / W / E (corresponding to channel Q), AK992.5.0-2.0(corresponding to channel W), AK992.5.0-3 (corresponding to channel E).

① Long press the Fn+Q or W or E key combination for 3 seconds to pair, the Q key light (blue light) flashes quickly to enter the pairing mode, and the Bluetooth device (Bluetooth 5.1 or above) can be paired and connected to the keyboard.

② Short press the Fn+Q/W/E key combination to switch the Bluetooth channel, the light of the paired Q/W/E key flashes slowly, the connection is successful, and the light returns to normal light effect.

2. 2.4G Wireless Connection: Fn+R

Long press Fn+R to enter 2.4G strong code pairing, the R button light flashes quickly to enter the code pairing mode, and the receiver is paired with the device. The code is successfully paired. (It has been paired before leaving the factory, and the number key is 1 to 6 drive the percentage of power).

3. Wired Mode Connection:

Toggle the switch to the “**|**” position, which is the wired mode.

4. Backlight Mode

Fn+L Lighting effect switching, 21 kinds of lighting effects cycle in turn

Fn+L (1), (2): 24 non-customizable three groups of game lighting effects (preset all white light)

Fn+L(1) : Default FPS mode : W / A / S / D / ↑ / ← / →

Fn+L(2) : Default LOL mode : Q / W / E / R / A / S / D / F / 1 / 2 / 3 / 4 / 5 / M

Fn+L(3) : Default LT key office mode: K / J / B (English letters) / ↑ / ← / ↓ / → / Tab / Space / 4 / 5 / M

Fn+ : Discard: Save the lighting mode for the lighting effects of the above three game modes, press the button once during the lighting effect of the above three game modes to discard the current lighting effect.

Fn+ ↑ : Light brightness - (five gears) adjusted to the highest backlight indicator flashes 3 times to indicate

Fn+ ↓ : Light brightness - (five levels) adjusted to the lowest backlight indicator flashes 3 times to indicate

Fn+ ← : Dynamic lighting direction switching

Fn+ → : Switch backlight color

Fn+ ← : Light speed - (five gears) adjusted to the lowest backlight indicator flashes 3 times to indicate

Fn+ → : Light speed - (five gears) adjusted to the lowest backlight indicator flashes 3 times to indicate

No Backlight Version

2. Description of the switch indicator light

Switch Function (Figure 1)

The three-speed toggle switch series 2.4G/USB/Bluetooth mode, and the default USB mode.

“**|||**” : Wired mode;

“**||**” : Bluetooth mode.

“**|**” : Wireless mode.

Indicator light: the top left of the keyboard is white light (picture 2)

1. Indicator “**|||**” : Num switch;
2. Indicator “**||**” : Caps switch;
3. Indicator “**|**” : 2.4G mode;
4. Indicator “**||**” : Bluetooth mode;
5. When the battery of the keyboard is low, all the indicators will flash continuously to indicate that it needs to be charged. (The device can be charged by connecting the USB cable in any wireless mode).

Scroll Wheel Function

① Volume adjustment function:

Turn the knob to the left: volume -

Turn the knob to the right: volume +

② Mute: Press to mute, then press to restore.

Note: By default, the volume adjustment will follow the computer, and the computer volume will jump 2 bars after turning one bar.

Sleep Mode

Power-Saving Sleep : After 5 minutes of inactivity, press any key to wake up the keyboard and connect back to Bluetooth (1.4).

Deep sleep: After 30 minutes of inactivity of keyboard keys, enter deep standby, Bluetooth (1.4) is disconnected and hibernates.

Press any key to wake up the keyboard and connect back to Bluetooth (1.4).

(Figure1)

(Figure2)

3. Mode Connection Description

1. Bluetooth Mode Connection: Fn+Q / W / E

Bluetooth connection: Fn+Q / W / E (corresponding to channel Q), AK992.5.0-2.0(corresponding to channel W), AK992.5.0-3 (corresponding to channel E).

① Long press the Fn+Q or W or E key combination for 3 seconds to pair, the Q key light flashes quickly to enter the pairing mode, and the Bluetooth device (Bluetooth 5.1 or above) can be paired and connected to the keyboard.

② Short press the Fn+Q/W/E key combination to switch the Bluetooth channel, the light of the paired Q/W/E key flashes slowly, the connection is successful, and the light returns to normal light effect.

2. 2.4G Wireless Connection: Fn+R

Long press Fn+R to enter 2.4G strong code pairing, the R button light flashes quickly to enter the code pairing mode, and the receiver is paired with the device. The code is successfully paired. (It has been paired before leaving the factory, and the number key is 1 to 6 drive the percentage of power).

3. Wired Mode Connection:

Toggle the switch to the “**|**” position, which is the wired mode.

4. Combination Key Function Description

Fn+F1 Multimedia player

Fn+F2 Volume down

Fn+F3 Volume up

Fn+F4 Mute

Fn+F5 Prev song

Fn+F6 Play/Pause

Fn+F7 Next song

Fn+F8 Calculator

Fn+F9 E-Mail

Fn+F10 My Computer

Fn+F11 My Browser

Fn+F12 Calculator

Fn+Esc Mute

Fn+Space bar: Press and hold for 3 seconds, the keyboard light flashes 3 times, clear the light effect and Bluetooth device indicator lights (only the function of the left window (Win key) left, the win key indicates that the white light is always on, indicating that it is locked, and it will return to normal after unlocking)

Fn+BACK Delete: Long press Fn+R for 3 seconds to pair with the receiver (2.4G Bluetooth mode), the backlight is off, and the lights of the number keys 1 to 6 drive the percentage of power.

5. Instructions for Hot Plug Operation Steps

Hot swappable: Different shafts can be replaced, and you can customize your unique typing experience. 3.5pin is compatible with most mechanical switches.

(Figure2)

① Calibrate pins and holes

② Horizontally and lightly press the switch

③ Both sides hold down the shaft

④ Vertically and lightly press the switch

⑤ Complete

5. Instructions for Hot Plug Operation Steps

Hot swappable: Different shafts can be replaced, and you can customize your unique typing experience. 3.5pin is compatible with most mechanical switches.

(Figure2)

① Calibrate pins and holes

② Horizontally and lightly press the switch

③ Both sides hold down the shaft

④ Vertically and lightly press the switch

⑤ Complete

5. Instructions for Hot Plug Operation Steps

Hot swappable: Different shafts can be replaced, and you can customize your unique typing experience. 3.5pin is compatible with most mechanical switches.

(Figure2)

① Calibrate pins and holes

② Horizontally and lightly press the switch

③ Both sides hold down the shaft

产品质保 (Product Warranty)

感谢您对我们产品的信任与支持，为了让您放心使用本产品，请仔细阅读以下质保说明，以确保您能享受到最佳的服务体验。

1. 质保期限：自购买日起，享有一年的质保服务。
2. 质保内容：在质保期内，若因产品本身的质量问题出现故障，我们将为您提供免费的维修或更换服务。
3. 不属于质保范围：
   a. 因超出常规使用范围或误操作导致的损坏；
   b. 因自然灾害、意外事故、人为破坏等不可抗力因素导致的损坏；
   c. 未经授权进行拆机、改装或维修导致的损坏；
   d. 因使用过程中产生的正常磨损、老化等自然现象；
   e. 因运输过程中发生的损坏；
   f. 超出质保期限的产品。
4. 客户责任：
   a. 请妥善保管好您的产品及其配件，以便日后维修或更换时使用；
   b. 在发现产品出现问题时，请及时与我们的客服团队联系，以便我们为您提供最快的解决方案；
   c. 请确保您提供的联系信息准确无误，以便我们能够顺利与您沟通。

质保卡 (Warranty Card)

产品型号：_____

序列号：_____

客户姓名：_____

联系电话：_____

联系地址：_____

*本产品不具备产品商品属性的重要信息，请妥善保管。

*此卡产品质保，可以在线登录官方网站查询。

合格证
AJAZZ | NACODEX
检验员：

关注公众号

关注抖音号

制造商：深圳市奥图科技电子有限责任公司
地址：深圳市龙华区大和路海关综合楼12层
电话：0755-27867390
澳门地址：澳门新口岸