1. Go to www.odtracking.com and click the LOG-IN button

2. Enter you LOGIN credentials

2. Under the ADMINISTRATION tab select GEO-ZONE ADMIN

4. Enter a name for your new geozone and click NEW

5. Select your newly created geozone and click EDIT

6. Enter an address and click the CENTER ON ADDRESS button to select and area. Alternatively, you may zoom in on an area and click it

7. The geozone can be moved by clicking on the middle pushpin and dragging it on the map. The outer radius can be changed by clicking and dragging the outer pushpin in and out

8. Click the CHANGE button to confirm the geozone area selection

9. From the ADMINISTRATION tab, select RULE ADMIN

10. Enter a name for your geozone alert (home,work,etc...) Then click NEW

11. Select your newly created rule and click EDIT

| | Main | Mapping | Reports | Administration |

View/Edit Rule Info

Select a Rule:

Select	Rule ID	Description	Selector	Cron Rule	Active
○	arrive_home	Geozone Arrive	$SYSRULE("arrive")	--	Yes
○	busstoparriveordepart	New Rule [busstoparriveordepart]		--	Yes
○	cobra_panic2	Panic On	$SYSRULE("panic")	--	Yes
○	cornering	Hard Cornering	$SYSRULE("hard_cornering")	--	Yes
○	depart_home	Geozone Depart	$SYSRULE("depart")	--	Yes
○	device-unplugged	Unplugged For 30 Min.	$SYSRULE("30minuterule2")	Daily	Yes
○	disconnected	Last Connect 30min	$SYSRULE("lastconnect30")	30 Minute	Yes
○	excess-idle	20min_excess_idle	$SYSRULE("20min_excess_idle")	--	Yes
○	fuel	New Rule [fuel]		--	Yes
○	general_speeding	Speeding	$SYSRULE("speeding")	--	Yes
○	hard_acceleration	Hard_Acceleration	$SYSRULE("hard_acceleration")	--	Yes
○	hard_braking	Hard_Braking	$SYSRULE("hard_breaking")	--	Yes
○	high-rpm	RPM	$SYSRULE("rpm")	--	Yes
○	highway_speeding	Speed over 75 MPH	$SYSRULE("speed75")	--	Yes
◉	home	New Rule [home]		--	Yes
○	ignition_off	Ignition Off	$SYSRULE("ignition_off")	--	Yes
○	ignition_on	Ignition ON	$SYSRULE("ignition")	--	Yes
○	oil-change	All Periodic Maintenance	$SYSRULE("maintkm")	Daily	Yes
○	on-the-move	Initialization/PoweredUp	$SYSRULE("initialization")	--	Yes
○	speed_100	High Speed	$SYSRULE("speed100")	--	Yes

[View] [Edit]   [Delete]

Create a new Rule:

Rule ID: [_____]

[New]

New Rule has been created

12. Choose where to send the alerts (geozone arrive, geozone depart, etc…)

| | Main | Mapping | Reports | Administration |

View/Edit Rule Info

Rule ID:	home
Notification EMail:	sales@odtracking.com
System Rule:	n/a
Active:	Yes
Cron Rule:	No (Used for periodic Rule triggering)
Description:	New Rule [home]
Rule Selector:	
Trigger Action:	EMail: ☑ Save/Alert: ☐ Queue: ☐ Listener: ☐
Minimum Interval:	0 (seconds)
Interval Reset:	Yes
EMail Subject:	
EMail Message:	

13. Select a SYSTEM RULE such as GEOZONE ARRIVE or GEOZONE DEPART

14. Select a vehicle or group of vehicles for this rule to apply to, then click the CHANGE button