Dual Security Kiosk Stand with Locking Case and Cable

PAD-ASKM6

INSTRUCTION - MANUAL

CONTENTS:

(A) x1
(B) x1
(C) x1
(D) x2
(E) x2
(F) x1
(G) x5
(H) x2
(I) x1
(J) x1

INSTALLATION:

1. Attaching Holder to Body

1A. Insert holder joint (C) into body joint (B) and align allen key hole.

1B. Screw the allen screw (D) into hole and securely tighten with provied allen tool (F).

2. Attaching Body to Base

2A. Insert base joint (A) into body joint (B) and alling allen key hole.

2B. Insert the allen screw (D) into hole and securely tighten with provided allen tool (F).

3. (Optional) Attaching Base Pads to Base

3A. Stick adhesive pads (G) to bottom of stand base (A) for scratch protection and temporary mounting.

4. Inserting Tablet into Enclosure

4A. Open the case (C) with the stand on a flat surface.

**Tablet only shown for illustration purposes, not included.

4B. Place your tablet device inside the tray (C).

4C. Close the case door and turn the key (I) clockwise to lock.

5. (Optional) Bolting to Countertop

5A. Aling the two screws (H) with the holes in the base (A).

5B. Screw in screws until securely attached to counter.

**Tablet and cable only shown for illustration purposes, not included.

4D. Internal cable routing.

6. Cable Management

**Tablet and cable only shown for illustration purposes, not included.

6A. Fish the cable wire through the top end of the kiosk body (B).

6B. Fish the cable wire out the other end as shown above.

7. Adjustability

7A. Adjust the joint rotation to the prefered angle.

**Tablet only shown for illustration purposes, not included.

7B. Adjust the orientation to the prefered view.

8. Security - Cable Lock

8A. Anchor the cable loop of your security cable lock (J) around an immovable object.

8B. Secure and lock the other end to the kiosk (A) into the cable lock slot hole as shown.