LITHIUM CARAVAN KIT
Wiring Diagram

Cables used to link batteries and Cable B- to Battery 1 must be the same guage (or better) as the cables used for connecting loads. E.g 3000W Inverter requires 2 AWG, then all cables must be atleast 2 AWG.

All positives from load chargers to Battery 3



iTECHWORLD

This wiring diagram is provided for professional installers only.
All work to be carried out by licensed professionals.