Akko

键 盘 用 户 手 册

MU01

User Manual
Benutzerhandbuch

快速开始指南 ▶
Quick Start Guide

为了给您带来更好的使用体验，在使用产品前请仔细阅读本说明书，并请妥善保管，以便日后参观。

产品介绍

包装内容


系统需求

Windows®XP / Vista / 7 / 8 / 10或更高版本

安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。

独立指示灯

状态	指示灯位置	回连	配对	连接成功
BT1	按键E灯	蓝灯慢闪	蓝灯快闪	蓝灯常亮2s熄灭
BT2	按键R灯	蓝灯慢闪	蓝灯快闪	蓝灯常亮2s熄灭
BT3	按键T灯	蓝灯慢闪	黄灯快闪	蓝灯常亮2s熄灭
2.4G	按键Y灯	绿灯慢闪	绿灯快闪	绿灯常亮2s熄灭
有线	按键U灯	无	无	红灯常亮2s熄灭

状态	指示灯位置	指示方式
低电		红灯慢闪
充电	空格键键位灯	红灯常亮
充满		绿灯常亮/恢复正常背光
Caps	Caps按键灯位	白灯常亮
锁WIN	左WIN键灯位	白灯常亮

MU01 组合键功能

Fn+	1-0	=	F1-F10
	-		F11
	=		F12
	PgUP		Home
	PgDn		End

Fn+	I	=	Insert
	P		PrtSc
	C		计算器
	M		静音
	<		音量减弱

Fn+	>	=	音量增强
	W		将W A S D与 ↑↓ ← → 键对调

MU01 系统功能 (Windows)

锁Win键	恢复出厂设置	切换成菜单键
Fn + 左Win	长按 Fn + BackSpace 5秒	长按Fn + 右Ctrl 3秒

MU01 系统功能 (Mac)

Fn+	1	=	降低显示屏亮度
	2		增加显示屏亮度
	3		开放任务控制
	4		呼出Siri
	7		上一曲

Fn+	8	=	播放/暂停
	9		下一曲
	0		静音
	-		调低音量
	=		调高音量

左 Win	Option		左 Alt	Command		右 Alt	Command

MU01 灯光调节

Fn+	Del	=	常亮（默认）、呼吸、霓虹、光波、涟漪、繁星点点、川流不息、如影随形、聚合、正弦波、彩泉涌动、百花争艳、一石二鸟、峰回路转、斜风细雨、雨滴、流星、踏雪无痕、极光、层出不穷、
	↑		灯光变亮
	↓		灯光变暗
	←		灯光方向向左
	→		灯光方向向右
	【		灯光速度变慢
	】		灯光速度变快
	L		灯光关闭/开启
	\		切换背光致7种单色+RGB循环

MU01 连接使用指南

Fn+	E	=	蓝牙设备1	短按回连
	R		蓝牙设备2	长按配对
	T		蓝牙设备3	
	Y		2.4G无线设备	
	U		有线模式	

开关位于 CAPS按键右侧	上：MAC (内置电源开)
	中：Windows (内置电源关)
	下：Windows (内置电源开)

蓝牙配对

键盘开机后，按下FN+E/R/T进入蓝牙模式，长按FN+E/R/T组合键3S，键盘进入对码状态，蓝色指示灯快闪，连上后指示灯常亮2S，如果没有连上设备指示灯熄灭，键盘进入睡眠。

2.4G配对

键盘开机后，按下FN+Y进入2.4G模式，再按下FN+Y组合键3S进入配对模式后，绿色指示灯快闪，插入接收器，配对成功后退出对码，模式灯常亮2S，找不到配对设备30s后，退出对码模式灯熄灭，键盘进入睡眠。

电量查询

在无线模式下，按Fn+空格组合键可检查电池电量。如果电池电量低于30%，数字1-2键将显示红灯。如果电池电量低于100%，数字1-9键将显示绿灯，电池电量充满则数字1-0键显示绿灯。

1	2	3	4	5	6	7	8	9	0
低于30%		低于40%	低于50%	低于60%	低于70%	低于80%	低于90%	低于100%	充满
亮红灯		亮绿灯							

按键/灯光自定义说明和调用说明

1. 键盘三种工作模式下均可连接驱动并进行灯光和按键自定义

2. 键盘三种工作模式下可搭配驱动实现音乐律动

3. 请在我司官网下载"Akko Cloud"驱动

4. 驱动下载地址www.akkogear.com

AKKO保修和服务声明

1. Akko为中国大陆的客户提供一年保修。对于其他地区，
   请联系您的卖家（Akko分销商）以了解具体的保修政策。

2. 如果保修期到期，客户需要支付维修费用。如果用户喜欢自己修理键盘，
   Akko也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。

3. 由于私自拆卸产品、使用不当和安装不当而导致的缺陷不在保修范围内。

4. 官方售后服务时间为每周一至周五上午10：00至下午18：00
   节假日以国家法定节日休息为准。

5. 退货和保修政策在不同的平台上可能有所不同，并在购买时取决于具体的经销商。

公司：深圳银宸科技有限公司
地址：深圳市宝安区松岗街道碧头第一工业区朗碧路33号
电话：0755-23216420
网址：www.akkogear.com
产地：中国 • 深圳
Company: Shenzhen Yinchen Technology Co., Ltd
Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China

⚠️ WARNING:
Water and Beverages can't be
poured into the Keyboard.

CE FC ♻ 🔋

中国制造 / Made in China

注意事项	人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等，键盘为电子产品请按照电子产品保护方式爱惜使用。

Packing List

Minimum System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version

Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB-A port to start using it.

LED Indicator Overview

Status	Indicator	Re-Connecting	Pairing	Connected
Bluetooth device 1	LED for Key E	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off
Bluetooth device 2	LED for Key R	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off
Bluetooth device 3	LED for Key T	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off
2.4G wireless device	LED for Key Y	Green light blinks slowly	Green light blinks fast	Green light stays on for 2 seconds and then turns off
Wired mode	LED for Key U	N/A	N/A	Red light stays on for 2 seconds and then turns off

| Status	Indicator	Indicating Mode
Low Battery	Independent LED Indicator (near spacebar)	Red light blinks slowly
Charging		Steady Red
Fully Charged		Green light stays on / Return to regular RGB settings
Caps	LED for Caps Key	Steady White
Lock WIN	LED for left Win Key	Steady White

MU01 HotKeys

Fn+	1-0	=	F1-F10
	-		F11
	=		F12
	PgUP		Home
	PgDn		End

Fn+	I	=	Insert
	P		PrtSc
	C		Calculator
	M		Mute
	<		Decrease Volume

Fn+	>	=	Increase Volume
	W		Swap W A S D with ↑↓←→

MU01 System Commands (Windows)

Lock Windows Key	Restore Factory Settings	Revert Ctrl into Menu Key
Press Fn and left Win Key	Hold down Fn and press BackSpace Key for 5S	Hold down Fn and press right Ctrl for 3S

MU01 System Commands (Mac)

Fn+	1	=	Decrease display brightness
	2		Increase display brightness
	3		Open mission control
	4		Activate Siri
	7		Skip back (Audio)

Fn+	8	=	Pause/Play (Audio)
	9		Skip forward (Audio)
	0		Mute
	-		Volume down
	=		Volume up

Left Win	Option

Left Alt	Command

Right Alt	Command

MU01 Backlight Settings

Fn+	Del	=	Effect 1-Effect 20
	↑		Bright
	↓		Dim
	←		Set animation direction to left
	→		Set animation direction to right
	[		Slower Animation
	]		Faster Animation
	L		Light Off/On
	\		This shortcut allows you to set the backlight color to 7 single color with RGB loop effect

MU01 Connection Guide

Fn+	E	=	Bluetooth Device 1		Short press to link back		Top: Mac (built-in power supply on)
	R		Bluetooth Device 2		Long press to pair		
	T		Bluetooth Device 3			The switch is located under the CAPS key	Middle: Default Windows (built-in power supply off)
	Y		2.4G Wireless Device				Bottom: Windows (built-in power supply on)
	U		Wired Mode				

Bluetooth Pairing

After turning on the keyboard, press FN+E/R/T to enter Bluetooth mode. Press and hold the FN+E/R/T Key combination for 3 seconds to enter pairing mode, with the blue indicator light flashing quickly. Once the connection is established, the indicator light will stay on for 2 seconds. If the device fails to connect, the indicator light will turn off and the keyboard will enter sleep mode.

2.4G Pairing

After turning on the keyboard, press FN+Y to enter 2.4G mode.Then press and hold the FN+Y Key combination for 3 seconds to enter pairing mode.Then insert in the receiver, and the green indicator light will flash quickly. Once the pairing is successful, the LED indicator will stay on for 2 seconds.If no available device is found within 30 seconds, the LED indiactor will turn off and the keyboard will enter sleep mode.

Battery Level Check

Press the Fn + Space Key combination to check the battery level while in wireless mode. If the battery level is below 30%, the LED for number keys 1-2 will turn red. If it's between 30-100%, the LED for number keys 1-9 will show a green light. And when the battery is fully charged, the LED for number keys 1-0 will show a green light.

1	2	3	4	5	6	7	8	9	0
Less than 30%		Less than 40%	Less than 50%	Less than 60%	Less than 70%	Less than 80%	Less than 90%	Less than 100%	Full charged
Red light		Green light							

Key/Lighting Effects Customization Instruction

1. The driver can be connected and lighting and key can be customized under the three working modes of the keyboard
2. The three working modes of the keyboard can be matched to drive the music rhythm
3. Please download the Akko Cloud driver on our website
4. Users can download the driver via en.akkogear.com

Akko Warranty and Service Statement

1. The keys can be remapped and RGB can be programmed in the driver in any of the connection mode

2. Keyboard lighting can be coordinated with the driver to achieve audio visualizer

3. Defects resulting from disassembly of our product, improper usage and incorrect installation are not covered by warranty.

4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd
Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China
Tel: 0755-23216420
Website: www.akkogear.com
Origin: Shenzhen, China

WARNING:
Water and Beverages can't be poured into the Keyboard.

中国制造/Made in China

instagram.com/akkogear

facebook.com/akkogear

tiktok.com/@akkogear

Precautions   Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.

www.akkogear.com

@akkogear

Akko艾酷时尚外设

扫描关注官方微博