Connecting product

1

.1 open

.2 CR123A 3V

.3 Close

2



3



4

.1 Sensors

.2 Smoke Detector (Wi-Fi)



5



6



.1 Hold MODE button 5 sec to reset

.2 Blinking 1x 0.5sec

7



8



9



For Your convenience we strongly recommend to rename your product. Please choose intuitive description

Due to constant development, our App design and functionality might be different after updates. Please adjust accordingly or visit robertsmart.com (v01)

robertsmart.com