nuwave®

OXYPURE® SMART AIR PURIFIER

POWER
AUTO
ULTIMATE CLEAN
FAN SPEED — LOW HIGH
RESET FILTER 2 HOLD FOR 2 SECONDS
TIMER — HR
RESET FILTER 4 HOLD FOR 2 SECONDS
TURBO — HR
AIR — CLEAN DIRTY
ODOR — NO ODOR STRONG ODOR

ECO-FRIENDLY MODE
SLEEP MODE
●WIFI ●CLEAN FILTER 2 ●REPLACE FILTER 4

Air/Odor Quality - Detects particles as small as 2.5/1000mm

Low PM Level					High PM Level
Particulate Matter (PM) with a diameter of 2.5 microns or less					
0~5	5~10	10~20	20~30	30~50	Over 50
Fan Speeds					
1	2	3	4	5	6

See the Owner's Manual for details.

Button	Name	Function	Use
(power icon)	**POWER**	Turns the OxyPure® on and off.	Press **POWER** to turn the OxyPure® on and off.
	Wi-Fi MODE	Allows you to connect the OxyPure to your Wi-Fi network	Press and hold **POWER** to initiate Wi-Fi pairing.
AUTO	**AUTO**	Allows you to run the OxyPure at the lowest fan speed, raising it based on PM level.	Press **AUTO** and the Auto back light will turn on. There is no time limit on the Auto Mode. Press **AUTO** again to deactivate Auto Mode.
(power) + ULTIMATE CLEAN	**ECO MODE**	Allows you to save energy by keeping the OxyPure fan off until it's needed.	Press and hold **POWER** and **ULTIMATE CLEAN** to activate Eco Mode. The Power icon backlight will be yellow while in Eco Mode.
ULTIMATE CLEAN	**ULTIMATE CLEAN**	Automatically switches to the highest fan speed when the PM level rises.	Press **ULTIMATE CLEAN** to activate the Ultimate Clean Mode.
FAN SPEED LOW HIGH	**FAN SPEED**	Adjusts the OxyPure's fan speed.	There are 6 fan speed levels. Press **FAN SPEED** to adjust from Speed 1 (lowest) to Speed 6 (highest).
SLEEP MODE	**SLEEP MODE**	Turns off the control panel LED lights but keeps the fan active.	Adjust the Fan Speed prior to activating Sleep Mode. Press and hold **FAN SPEED** for 2 seconds to activate Sleep Mode.
TIMER HR	**TIMER**	Sets a countdown timer to shut off the OxyPure or end the current function.	Press **TIMER** to select from the 6 timer settings of 1/2, 1, 2, 4, 8 or 12 hours.
TURBO HR	**TURBO**	Operates at fan speed 6 for a set time.	Press TURBO to set the OxyPure to run at the highest speed for 1/2, 1 or 2 hours.
AIR CLEAN DIRT	**AIR**	Air Quality Indicator	The color coded display shows the current particulate matter level in the air.
ODOR NO ODOR STRONG ODOR	**ODOR**	Odor Indicator	The color coded display shows the current odor level in the air.

Before Use

1. Make sure the OxyPure® is unplugged. Open the panel on the back to expose the filters.
2. Pull the filters from their slots.
3. Remove the plastic wrapping from the filters.
4. Fully reinsert the filters into the Oxypure and close the panel.
5. Remove the sticker from the control panel.

🛜 Wi-Fi Connection (Optional)

Connect the OxyPure to your home Wi-Fi network and pair it with your smart device:

1. Download the NuWave® Connect app via the Apple Store or Google™ Play Store on your smartphone or device and open the app.

   [Google play] [App Store]

2. Once you download the **NuWave® Connect app**, ensure your phone is connected to your home Wi-Fi network on the 2.4GHz frequency and that your phone's Bluetooth is on.
3. Turn on the OxyPure and activate Wi-Fi Pairing Mode by pressing and holding ⏻**POWER** until the light next to the **Wi-Fi** symbol begins to blink rapidly.
4. In the NuWave® Connect app, tap the **+** symbol, then tap **Auto Scan** and select your device.
5. Enter your **Wi-Fi** network's password and tap Confirm. If the connection is successful, the app will display "Added Successfully" on the screen.

If you're unable to pair your OxyPure using Auto Scan, follow the instructions for AP Mode or EZ Mode on page 9 of the owner's manual.

Wi-Fi LED Status Pairing Mode & AP Mode	
Solid Light	The OxyPure® is paired with the Wi-Fi and ready to be used.
Rapid Blinking Light	The OxyPure is in Pairing Mode. The OxyPure will remain in Pairing Mode for up to 3 minutes, or until your device is paired.
Slow Blinking Light	The OxyPure is in AP Mode.
No Light	The OxyPure's Wi-Fi is off.

Filters

1 Stainless-Steel Prefilter (Lifespan up to 20 years)
- Made from rust-free 18/8 stainless-steel.
- The durable, washable and reusable Prefilter captures and collects large particles

2 Bio-Guard® Filter (Lifespan up to 20 years)
- The 8,000-volt electrostatic filter captures airborne particles as small as 0.1 microns..

3 Ozone (O_3) Emission Removal Filter (Lifespan up to 20 years)
- Eliminates harmful ozone gas from the home, reducing ozone levels to less than 1 ppb – 70 times lower than the EPA's household standard of 70 ppb.

4 2-in-1 HEPA/Carbon Filter (Lasts up to 1 year)
- The double-sided filter traps airborne particles like pollen and pet dander while also trapping smoke, unwanted odors and VOCs.

Air Filter Assembly

When maintaining the filters, unplug the unit and open the Filter Access Panel. You will see that the order of the filters, from the outside in, is as follows:

1 Stainless-Steel Prefilter

2 Bio-Guard® Filter

3 Ozone Emission Removal Filter

4 HEPA/Carbon Filter

⚠ CAUTION

Unplug the OxyPure® from the power source before inserting or removing any parts or attachments and before cleaning.

The OxyPure® is easily movable with wheels on the bottom. Before moving your OxyPure, turn it off and unplug it from the outlet. Your settings will be saved and will automatically activate next time the unit is turned on.

Cleaning & Maintenance

Filter Maintenance Indicator

- The **FILTER 2** light will turn green after about 3 months to alert you that the Bio-Guard filter **SHOULD** be cleaned to maintain optimal performance. The light will turn red after about 6 months, indicating that the Bio-Guard filter **MUST** be cleaned. Once cleaned, press and hold **TIMER** to reset the indicator light.

- The **FILTER 4** light will turn green after about 6 months to alert you that the HEPA/Carbon filter **SHOULD** be replaced to maintain optimal performance. The light will turn red after about 12 months, indicating that the HEPA/Carbon filter **MUST** be replaced. Once replaced, press and hold **TURBO** for 2 seconds to reset the indicator light.

Cleaning the Filters

The filters need to be cleaned on schedule to help the unit maintain optimum performance.

1. Remove the Filter Access Panel in the r ear of the OxyPure® using its built-in handle.

2. Slide out the filters that need cleaning and spray with a mild detergent, then wipe clean.

3. Always allow the washable filters to dry completely, out of direct sunlight, before you reinstall them. Never place a wet filter into the OxyPure.

4. Reattach and close the Filter Access Panel. If the panel is not properly closed, the **POWER** button will blink red and the unit will not power on.

NOTE: The HEPA/Carbon filter cannot be cleaned.

Customer Service: help@nuwavenow.com

General Filter Cleaning Tips

1. **Always Wear a Mask and Use Rubber gloves.**
   Prevents accidental inhalation of any contaminants when cleaning your filters.

2. **Move the OxyPure, Not the Filters**
   Minimizes filter shaking.

3. **Handle the Filters Carefully**
   Be careful not to agitate the filters to avoid releasing trapped contaminants.

4. **Dry the Filters Completely**
   Never install a wet or damp filter into your OxyPure.

To Clean the Ozone Emission Removal Filter

1. Remove the filter. If possible, take them outside to clean.
2. Gently, but thoroughly, clean the filter using a brush-tipped vacuum.
3. Repeat the process on the other side. DO NOT GET WET.

To Clean the Stainless-Steel Prefilter

The Prefilter needs to be cleaned at least once every two months, depending on use.
1. Use a brush-tipped vacuum to remove any dust or lint.

Cleaning the Odor Sensor

1. The Odor Sensor is behind the three slots above the Dust Sensor Cover and may **ONLY** be cleaned using a brush-tipped vacuum.

Note: If you are unable to close the Filter Access Panel for any reason, the OxyPure will not operate and you will need to contact NuWave Customer Service. **Exercise caution to ensure the tabs are not damaged when securing the Filter Access Panel.**


NUWAVE®

OXYPURE® SMART AIR PURIFIER

Cleaning the Dust Sensor

The Dust Sensor is located on the side of the unit.

1. Open the Dust Sensor Cover.
2. Using a dry cotton swab, gently remove any dirt or dust from the Dust Sensor.
3. For more buildup on the Dust Sensor, wipe it with a slightly wet cotton swab.
4. Remove any moisture with a dry cotton swab.

NOTE: Consult the OxyPure Owner's Manual for more detailed cleaning instructions.

Do not immerse the OxyPure in water. Clean the outside of the unit with a damp sponge or cloth and wipe it dry. Make sure all parts and covers are securely attached.

Do not dry the filters in direct sunlight or with a hot blow dryer.

Sensor Cover

Lift the Air Vent

Inner Vent

Screws

Open

EPA Establishment Number: 101594-CHN-1