

FLC34
PW Boomerang
Advanced Series

Age Range:	3 years and up
Weight Limit:	100 Lbs.
Surfaces:	Grass/Hard Surfaces
Speed:	2.5 mph For/ Low/Rev
	5.0 mph Forward
Colors:	Purple Body/Black Wheels
Intro:	2017
Suggested Retail:	$419.99
Box Dimensions:	36.5" L x 20.5" W x 51" H
Warranty:	One Year Vehicle
	Six Months Battery

POWER WHEELS by Fisher-Price®

Item	Part #	Description	QTY
1	3900-6009	Bumper for Boommerang FLC33	1
2	3900-6010	Bumper Support for Boomerang FLC33	1
3	3900-6648	Pivot Shields for Boomerang	1
4	**3900-6035**	**Left Front Motor Gearbox Assy**	**1**
5	NA	Steering Linkage	1
6	3900-6646	Pal-Nut for Boomerang	2
7	3900-6024	Ring Pin for Boomerang FLC33	2
8	3900-6014	Axle cap for Boomerang	2
9	3900-6087	Right Fender for Boomerang FLC34	1
10	3900-6647	2 cm Washer for Boomerang	2
11	3900-6013	Wheel Cap for Boomerang FLC33	2
12	3900-6031	Front Wheel w/Rim for Boomerang	2
13	3900-6085	Left Fender for Boomerang FLC34	1
14	**3900-6082**	**Footboard Assembly Boomerang**	**1**
15	**3900-6020**	**Shifter for Boommerang FLC33**	**1**
16	**3900-6022**	**Circuit Board (EMU) for Boomerang**	**1**
17	3900-6674	EMU Cover for Boomerang	1
18	3900-6025	Steering Column for Boommerang	1
19	3900-6023	Rear Axle for Boomerang FLC33	1
20	3900-6008	Hood for Boomerang FLC33 (black)	1
21	3900-6083	Front Panel for Boomerang FLC34	1
22	3900-6012	Steering Wheel Retainer Boomerang	1
23	3900-6089	Steering Wheel w/Wire for FLC34	1
24	3900-6011	Steering Wheel Cover for (FLC33)	1
25	3900-6088	Seat for Boomerang FLC34	1
26	**3900-6034**	**Rear Wheel Assembly for FLC33**	**1**
27	3900-6006	Floorboard for Boomerang FLC33	1
28	See #3	See #3	

Item	Part #	Description	QTY
29	**3900-6036**	**Right Front Motor Gearbox Assy**	**1**
30	**3900-6037**	**Rear Motor Gearbox Assy**	**1**
31	**3900-6038**	**Front Axle for Boomerang FLC33**	**2**
32	**3900-6216**	**Motor Gearbox Cover Boomerang**	**2**

Parts Not Shown

Part #	Description	QTY
3900-4607	**Gearbox for Wild Thing / Boomerang**	**3**
3900-6019	**Motor Pinion Assembly Boomerang**	**3**
3900-6040	**Drift Switch Harness for Boomerang**	**1**
3900-6039	**Pedal Switch for Boomerang**	**1**
00801-1520	**Switch Signalux - 2 prong**	**1**
00801-1661	Battery 12v 9.5Ah (orange top)	1
00801-1778	12 Volt Charger w/Probe	1
3900-6021	Battery Retainer for Boomerang	1
3900-5463	Seatbelt Set (2 short straps)	1
3900-6016	Parts Bag for Boomerang FLC33	1
3900-6015	Hardware Bag for Boomerang FLC33	1
3900-6084	Label Sheet for Boomerang FLC34	1
3900-6086	Manual for Boomerang FLC34	1

Bold and underlined parts are to be purchased and installed by Service Centers only. These items may not be sold directly to consumers by Service Centers or Fisher-Price.

10/3/2018 8:07