
Power indicator
Reset button
Antenna
Controller
GND
+12...24 V DC
Ch1
Ch2
Ch24
(white) Sensor 2 signal
(red) Sensor 2 +12 V
(black) Sensor 2 GND
(black) Sensor 1 GND
(red) Sensor 1 +12 V
(white) Sensor 1 signal
Sensor 1
Sensor 2