WESTGATE
THE FUTURE IS HERE... AND IT'S QUITE BRIGHT

INSTALLATION INSTRUCTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND SAVE THEM, AS YOU MAY NEED THEM AT A LATER DATE.

CAUTION: TURN OFF POWER FROM THE MAIN CIRCUIT BEFORE INSTALLING FIXTURE.
Make sure fixture is grounded per National Electrical Codes (NEC). These fixtures are intended to be mounted to a metal outlet box. The box must be directly supported by the building structure. This fixture is suitable for wet locations.



1. Remove the screws, Adjust CCT switch near the driver of fixture accordingly to the desired color temperature.Then tighten the screws.



2. Remove the wire cover and metal plate from fixture, expose the wires.



3. For mounting the metal plate to the wall, mark four spots. Drill four holes on the target. Insert four anchors through the holes of the wall.



4. Attach the drywall screws through the holes of the metal plate and secure the drywall screws to the anchors.



5. Connect the cover to the fixture with four screws, make sure the wires through the circle hole of the cover. Make all wire connections to appropriate wire. Secure with wire nuts(provided). Then tuck all connections neatly into junction box.



6. Use two securing nuts with rubber washers to tighten up the bracket to the wall.

After mounting the fixture, caulk the suface between the fixture and the mounting surface.
Installation complete, Turn power on.