WAZO

ASSEMBLY INSTRUCTIONS

AX1	BX1	CX4
		

DX16	EX16	FX1	Extra Hardware
			D-2 pcs E-2 pcs

1



WAZO

ASSEMBLY INSTRUCTIONS

2