Uniform Medium
2 Door Cupboard

Size (mm): 800W x 450D x 1170H

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

ASSEMBLY INSTRUCTIONS
Uniform Medium
2 Door Cupboard
Size (mm): 800W x 450D x 1170H

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

A   B   C   D

E   F   G

COMPONENTS

A	Minifix Housing x16	E	Adjustable Leveller N2880 x5
B	Collar Stud x10	F	Leveller N2880 Cap x5
C	Rubber Wood Dowel M8x40mm x12	G	Deco Cap x5
D	Minifix Connecting Bolt x16	H	Safety hook *

PANELS

Top Panel x1
Back Panel x1
Side Panel x2
Base Panel x1
Shelf Panel x2
Top Rail x1 (*)
Door Panel x2

DOOR ASSEMBLY

5/8 Door Hinge c/w Mounting Plate x4
Chipboard Screw 4x16mm x24
CSK Tapping Screw #4 3/4" x4
Rim Lock CL 2/3 x1
Pan Head Self Tapping Screw x4
L Huwil Bracket x1
Plate Bracket BK x1

Top rail

Top panel

Back panel

Side panel

Door Panel Left

Door Panel Right

Base panel

Shelf panel

(*) The top rail is only required when assembling this unit with doors.

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

Function of Klix Cam
Turn for locking
75° Min - 195° Max

Make sure the arrow is pointing upwards before inserting into the panel's hole.

01

Back Panel

Top Panel

Side Panel R

Top Rail

Tighten Minifix Connecting into Boring Hole.

Insert collar stud into boring holes, at the height you want shelves.

Insert Minifix Housing into Boring Hole.

Side Panel L

Base Panel

Shelf Panel

Assemble all panels in the following order.

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

02

Adjustable Leveller
N2880

Leveller N2880 Cap

DECO-CAP-18X15
5-pcs

Tighten leveller into boring hole and screw the cap.
Use DECO-CAP-18X15 to seal holes on base panel.

Uniform Medium
2 Door Cupboard

Size (mm): 800W x 450D x 1170H

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

03

Boring hole

Tighten screw

Align handle with boring hole and screw

Plate bracket

Tighten screw

Place bracket at center and screw to the door

Align and mount hinge into door boring hole

Strike plate sits on top of the shelf facing downward

Plate bracket

CL2 Rim Lock

Stripe handle

Door hinge

Tighten leveller into boring hole and screw the cap.
Use DECO-CAP-18X15 to seal holes on base panel.

If you have purchased storage units that are 1600mm or 2400mm wide

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

1

Assemble each module separately without top

2

Add single top over all modules

Tighten Minifix Connecting into Boring Holes

2400mm

1600mm

module 1
800mm

module 2
800mm

module 3
800mm

Uniform Medium
2 Door Cupboard

Size (mm): 800W x 450D x 1170H

jason.l
your office furniture mate

Safety hook *

Large furniture provides ample storage space while making your home look great. If you have kids at home, you should firmly secure your large and heavy furniture to prevent it from toppling.



First set the location for install

Select the location where the wall is installed and punch ⌀8 mm

Install the screw expansion tube into the hole

Mounting screws

Choose a location that is fixed in the furniture

Adjust the distance of the connecting belt and complete the installation

JasonL strongly recommends that the safety hook will be utilized in all circumstances to prevent falls when the bookcase is installed on uneven ground, is unevenly packed or is interfered with by pets, children, or as a result of any other household or commercial activity. We disclaim all liability for any loss occasioned in the event that the safety hook is not used or has been improperly installed

Components included