ASSEMBLY INSTRUCTIONS
Quadro Square desk

Size: 1000L x 600W mm

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

Tools Required: Power screwdriver; Allen key set (provided)

👤👤 2 persons required for installation

ASSEMBLY INSTRUCTIONS
Quadro Square desk

Size: 1000L x 600W mm

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

COMPONENTS

A   Table top x1

B   Legs Quadro Square x2

C   Beam x1 *

D   Plastic bracket x4

SCREWS

E   M8x20MM CSK x1

F   M8x20MM Socket head x1

G   M6x20MM Socket head x2

H   M6x30MM Socket head x2

I   Allen key x2

*   Colour of the beam is always black, regardless desk frame colour.

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

STEP 01

(G)

Using Allen Key provided, attach 2 plastic brackets per leg **(D)** (as per picture above) using M6x20MM **(G)** Socket head screw

---

STEP 02

(F)

Using Allen Key provided, attach M8x20MM Socket head **(F)**- screw socket half way into leg for both legs **(B)**

STEP 03

Use fixed beam **(C)** 1000mm and secure beam using screws provided to suit 1000mm desk

ASSEMBLY INSTRUCTIONS
Quadro Square desk

Size: 1000L x 600W mm

www.jasonl.com.au

Need help!
Call us on
**1300 527 665**

jason.l
your office furniture mate

STEP 04

TOP VIEW

STEP 05

Attach beam **(C)** to legs **(B)** using nut insert in legs
See point attached

Frame looks like this. Using Allen Key, attach beam **(C)** with Socket **(E)**

Quadro Square desk

Size: 1000L x 600W mm

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

STEP 06

H

TABLE TOP
BOTTOM VIEW

nut insert

nut insert

Place desktop ontop of frame. Nut inserts in top will align with plastic joiner brackets using M6x30MM **(H)** sockets attached top to frame.