Music Stand
Tutorial

CODA MUSIC® TECHNOLOGIES

Make sure your STOMP Bluetooth Pedal is powered on and paired successfully with your tablet.

3:25 PM Wed Jan 30

Settings

🔍 Search

RH **Rob**
Apple ID, iCloud, iTunes & App St...

✈️ Airplane Mode

📶 Wi-Fi   Loons

🅱️ Bluetooth   On

🔔 Notifications

🔊 Sounds

🌙 Do Not Disturb

⏳ Screen Time

⚙️ General

🎛️ Control Center

🔤 Display & Brightness

🌸 Wallpaper

🌀 Siri & Search

🔒 Passcode

🔋 Battery

Bluetooth

Bluetooth   ✅

Now discoverable as "Rob's iPad (old)".

MY DEVICES

Coda Music Tech   Connected ⓘ

OTHER DEVICES

Open Music Stand and click the settings link

Under the CONTROL section, select "Pedal & Keyboard Input

With your STOMP Bluetooth Pedal powered on and paired with your tablet, select the command function you wish to adjust.

NOTE: In this example, we are using MODE 2, which sends an up/down arrow command. We are assigning the left foot switch to Previous Page and the right foot switch to Next page.

Next, press the foot switch on STOMP that you want to assign to that command function.

Note: Music Stand registers the Up Arrow in MODE 2 (Right foot switch) as "Port 3" and the Down Arrow (Left foot switch) as "Port 1". The Left and Right Arrow in MODE 1 register as Left and Right Arrow.

Repeat the process for the next command function you want to control and press the corresponding foot switch on STOMP.

Go back using the Settings tab

Press done to close the settings. Now you're ready to control Music Stand with STOMP.