FENDER MODEL "BASSMAN-AMP AB 165" LAYOUT

D-FE

P/B

NOTICE

VOLTAGES READ TO GROUND WITH ELECTRONIC VOLTMETER. VALUES SHOWN + OR - 20 %.

* - WHEN INSTALLING NEW 6L6's RESET HUM BALANCE FOR MIN HUM.



NOTE- ALL RESISTORS ½ WATT, 10 % TOLERANCE, IF NOT SPECIFIED.

NOTE- ALL CAPACITORS AT LEAST 400 VOLT RATING IF NOT SPECIFIED.

Fender

MUSICAL INSTRUMENTS
a division of Columbia Records Distribution Corp.
FULLERTON, CALIFORNIA
U S A.