RAM UNI-CONN™ ASSEMBLY GUIDE FOR APPLE IPAD

PARTS INDEX

A.) 1-QTY. IPAD DOCKING CRADLE ASSEMBLY
CRADLE TYPE MAY VARY
B.) 1-QTY. STEEL CLAMP PLATE
C.) 2-QTY. #4-40 X 1.25" FLAT HEAD MACHINE SCREWS
D.) 1-QTY. BOTTOM DOCK COVER
E.) 2-QTY. CABLE TIES (1 SPARE)
F.) 1-QTY. MOUNTING HARDWARE
(4 LONG SCREWS, 4 SHORT SCREWS, 4 NUTS)



FOR SQUEEZE-TYPE DOCKING CONNECTORS, USE SPARE (E) CABLE TIE TO PERMANENTLY PRESS SIDES TOGETHER.

FOR NON-LOCKING HOLDERS: USE CAUTION WHEN INSERTING AND REMOVING iPAD FROM RAM CRADLE. GENTLY DEFLECT TOP OF ROLLER TO KEEP iPAD SAFE. AVOID QUICK SNAPPING MOTIONS

1. (OPTIONAL) INSERT (E) CABLE TIE THROUGH SLOT ON BACK OF (A)DOCK FOR WIRE RETENTION.



2. INSERT CONNECTOR THROUGH BOTTOM OF (A) DOCK. FRONT SIDE OF CONNECTOR MUST FACE APPROPRIATE DIRECTION.

3. CAREFULLY PRESS CONNECTOR SO PINS FULLY PROTRUDE FROM CENTER SLOT.



4. INSERT USB SIDE OF CABLE THROUGH (B) CLAMP PLATE. INSERT CLAMP PLATE INTO (A) DOCK.



5. ATTACH (C) SCREWS TO HOLES ADJACENT TO PINS USING PHILLIPS HEAD SCREWDRIVER UNTIL SNUG.
DO NOT OVER-TIGHTEN

6. ATTACH (D) BOTTOM COVER TO (A) DOCK, SLOTTED SIDE FACING BACK.

7. (OPTIONAL) TIGHTEN (E) CABLE TIE AROUND POWER CABLE TO PROVIDE CABLE RETENTION.

USE APPROPRIATE LENGTH (F) SCREWS AND NUTS FOR ATTACHING TO RAM MOUNT

RAM MOUNTS MADE IN USA Your Best Connection

RMR-INS-AP8D

National Products, Inc., 8410 Dallas Ave S., Seattle, WA 98108, (206) 763-8361 www.ram-mount.com

RAM UNI-CONN™ ASSEMBLY GUIDE FOR APPLE IPAD

PARTS INDEX

A.) 1-QTY. IPAD DOCKING CRADLE ASSEMBLY
CRADLE TYPE MAY VARY
B.) 1-QTY. STEEL CLAMP PLATE
C.) 2-QTY. #4-40 X 1.25" FLAT HEAD MACHINE SCREWS
D.) 1-QTY. BOTTOM DOCK COVER
E.) 2-QTY. CABLE TIES (1 SPARE)
F.) 1-QTY. MOUNTING HARDWARE
(4 LONG SCREWS, 4 SHORT SCREWS, 4 NUTS)



FOR SQUEEZE-TYPE DOCKING CONNECTORS, USE SPARE (E) CABLE TIE TO PERMANENTLY PRESS SIDES TOGETHER.

FOR NON-LOCKING HOLDERS: USE CAUTION WHEN INSERTING AND REMOVING iPAD FROM RAM CRADLE. GENTLY DEFLECT TOP OF ROLLER TO KEEP iPAD SAFE. AVOID QUICK SNAPPING MOTIONS

1. (OPTIONAL) INSERT (E) CABLE TIE THROUGH SLOT ON BACK OF (A)DOCK FOR WIRE RETENTION.



2. INSERT CONNECTOR THROUGH BOTTOM OF (A) DOCK. FRONT SIDE OF CONNECTOR MUST FACE APPROPRIATE DIRECTION.

3. CAREFULLY PRESS CONNECTOR SO PINS FULLY PROTRUDE FROM CENTER SLOT.



4. INSERT USB SIDE OF CABLE THROUGH (B) CLAMP PLATE. INSERT CLAMP PLATE INTO (A) DOCK.



5. ATTACH (C) SCREWS TO HOLES ADJACENT TO PINS USING PHILLIPS HEAD SCREWDRIVER UNTIL SNUG.
DO NOT OVER-TIGHTEN

6. ATTACH (D) BOTTOM COVER TO (A) DOCK, SLOTTED SIDE FACING BACK.

7. (OPTIONAL) TIGHTEN (E) CABLE TIE AROUND POWER CABLE TO PROVIDE CABLE RETENTION.

USE APPROPRIATE LENGTH (F) SCREWS AND NUTS FOR ATTACHING TO RAM MOUNT

RAM MOUNTS MADE IN USA Your Best Connection

RMR-INS-AP8D

National Products, Inc., 8410 Dallas Ave S., Seattle, WA 98108, (206) 763-8361 www.ram-mount.com