



Model# CQADM900W Maintenance Instructions

1. DM900-0855 – Carbon Prefilter – Change every 2-3 months (or as needed) with arrow pointing towards the center of the unit. This filter is located behind the Filter Access Door. To open, simply turn the thumb-screw counterclockwise.
2. DMH4-0400 – HEPA Media Filter – Change every 2-3 years (or as needed) with arrow pointing towards the center of the unit. This filter is located behind the Filter Access Door. To open, simply turn the thumb-screw counterclockwise.
3. DM900-0191 – Germicidal UVC Lamps – Change every 2-3 years (or as needed) Use a soft cloth or cloth gloves when handling bulbs so dirt/oil from your hands does not get on the glass. You should hear the bulb click into place. To change these bulbs, open the Lamp Access Panel (3 screws) and remove the PCO filter and Final Filter.
4. DM900-0450 – PCO filter – Change every 2-3 years (or as needed). To change this filter, open the Lamp Access Panel (3 screws).
5. DM900-0810 – Carbon +Potassium Permanganate final filter – Change every 12 months (or as needed) with the arrow pointing towards the center of the unit. To change this filter, open the Lamp Access panel (3 screws).

