



CQASA900VS Maintenance Instructions

1. DM900-0855 – Carbon Prefilter – Change every 2-3 months (or as needed) with arrows pointing towards the center of the unit. This filter is located behind the Filter Access Door. To open, simply turn the thumb-screw counterclockwise.
2. DMH4-0400 – HEPA Media Filter – Change every 2-3 years (or as needed) with arrows pointing towards the center of the unit. This filter is located behind the Filter Access Door. To open, simply turn the thumb-screw counterclockwise.
3. DM900-0191 – Germicidal UVC Lamps – Change every 2-3 years (or as needed) Use cloth gloves when handling bulbs so dirt or oil from your hands doesn't get on the glass. You should hear the bulbs click into place. To change these bulbs, open the Lamp Access Panel (3 screws) and remove the PCO filter and Final Filter.
4. DM900-0450 – PCO filter – Change every 2-3 years (or as needed). To change this filter, open the Lamp Access Panel (3 screws).
5. DM900-0810 – Carbon+Potassium Permanganate final filter – Change every 12 months (or as needed) with arrows pointing towards the center of the unit. To change this filter, open the Lamp Access panel (3 screws).

