

Instructions

Instructions for use of ultraviolet germicidal lamp:

Please leave the room within 10 seconds after opening. During use, people and animals shall not stay at the site to avoid skin burns. If you need to observe the use of germicidal lamp, please do not use the naked eye to directly look at the lighted lamp tube to avoid eye swelling or burning.

After disinfection, please open doors and windows for ventilation and enter the room 15 minutes later. If the sterilized lamp with ozone is used, please continue to close the door and wait for 10 minutes after use, and then open the door for ventilation for 20 minutes before entering

It is recommended to protect the high grade silk, leather, calligraphy and painting, precious collection and items with important commemorative significance from the light; it is not recommended to put them on the white bedspread or tablecloth for disinfection, so as to avoid fading caused by too strong ultraviolet.

After disinfection, please turn off the power of the sterilization lamp to prevent unnecessary injuries caused by children or pets accidentally turning on the touch switch.

Features: disinfection, sterilization, mite removal, odor removal, formaldehyde removal

Place of use: family, school, hospital, office, etc