6.5" x 6.5" trimline





FLEX_IM_TS_071719

FIG 2.

- FIG 1. 31 3 31 3 31 3 31 3 31 3 31 3
- 4. The unit now can be placed on the back plate and the magnetized back

WARNING - Painted surfaces may be damaged upon removal of the peel & stick adhesive on back plate. Use care when removing back plate from surface. TIP ON REMOVING ADHESIVE PLATE - Use a fine string or dental floss and work it between the adhesive and the surface using a back & forth motion to saw through the adhesive bit by bit. Then use rubbing alcohol to remove any sticky

NOTE: The unit does not need the back plate when applying directly to metallic surfaces - the magnetized back of unit will adhere to metallic surface.





TO CLEAN: Wipe with damp cloth. Do not use harsh chemicals to clean.

CAUTION: When applying to wall, ensure the mounting area surface is not in an area that has heavy vibration or on moveable area such as a door surface. This can cause the unit to lose the hold and fall off.

WARNING: DO NOT LOOK DIRECTLY INTO THE LIGHT WHEN IT'S ON-VISION MAY BE IMPARIED.

BATTERY CARE, USE, & DISPOSAL TIPS:

- Use correct size batteries as per specifications. Insert batteries correctly, with the + and - terminals aligned properly.
- Do not mix old with new batteries for optimum performance.
- Do not mix different types of batteries (for example Alkaline with Zinc Chloride, or rechargeable in same device).
- Recycle batteries as per your local area guidelines.
- Never dispose Batteries in fire as they could explode.
- For more information on battery responsibility go to: www.batteryresponsibility.org

WARNING: This product contains Magnets. Can be harmful to those who have a Pacemaker, Defibrillator or other medical implants. Failure to follow warning can result in serious injury.

LIMITATION OF LIABILITY

Liability is limited to the purchase price of this product. Trendstar Corporation shall not be responsible for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. For questions or comments on product please send email to admin@trendstarinc.com

- Please allow 48 hours for a response.