

Instruction Manual

1.Preparation

1.1 Search “Smart Life ” & “Tuya Smart ” in Google Play or App Store and have it installed on your smartphone.

1.2 Activate Bluetooth connectivity on your smartphone.

2.Operating Instructions

2.1 Screen Display

Bluetooth connection status indicator

Battery charge indication

Number of current the probe



Touch button:

1. Tap to shift between readings from the 4 probes.

2. Tap to mute the alarm (when an alarm sounds).

3. Tap twice rapidly to reverse the screen display.

Temperature unit.

2.2 Power On

Slide the switch on the back side to ON position.

2.3 Probe Installation

Insert the plug of the probe(s) into the socket(s) located on the two sides of the food thermometer. When the plug is fully inserted, you'll hear a “click” sound and the temperature reading of the probe will display on the screen.

Please insert the probes into food and make sure the probe tip is at the center position of the food so as to acquire accurate temperature readings.

2.4 Pair the thermometer to your smartphone

Before pairing, please remove all probes from the device.

2.4.1 Launch “Smart Life ” on your phone and make sure Bluetooth connectivity is active.

2.4.2 Press and hold the touch button to activate the pairing mode with the Bluetooth indicator flashing.

2.4.3 Tap “+ ” on the upper right corner on the phone screen, it will automatically find the device to be paired. Tap the device name to complete the pairing.

2.4.4 The device will be instantly operational when it is added.

2.5 Functions

2.5.1 Set a target temperature

In “ Home ” page, choose a probe connected to the thermometer and tap “Please set the scene” .

Choose a food with its preset taste (temperature) or customize per your preferences, then press “Start” .

Insert the probe into food and start heating, making sure that the probe tip is at the centre of food.

When the target temperature is reached, the device will sound an alarm and a notification will be pushed to your phone. Tap “Confirm” in the app or tap the touch button on the device to mute the alarm. When the food is cooked, tap “Stop” in the app.

2.5.2 Countdown Timer

Tap “Timing” on the bottom and then tap “Add” .

Set the countdown time for a desired probe and then tap “Save” on the top right. The countdown starts immediately.

Once the countdown time is up, the device will sound an alarm and a notification will be pushed to your phone.

2.5.3 Change the temperature unit

You can change the temperature unit of the thermometer in the “Setting” page in the app.

2.5.4 Reverse the screen display

You can rotate the screen display by 180 degrees with a rapid double tap on the touch button.

The device can be charged with the Micro USB port on the top side. When fully charged, the device can be used for up to 16 hours.

The device can be fixed on metal surfaces with its magnetic back.

Tips:

1.Continuous temperature measuring limit: 250° C.

Temporary temperature measuring limit; 300° C.

Exceeding the limits will melt and destroy the probe and its cable.

2.Do not place the thermometer close to heating source.

3.The device is not waterproof.

4.If the app shows no probes, please restart the device or re-plug the probe(s).



CENTURY PRODUCTS INC.
Customer Service Assistance: 1.909.592.1881
Email: support@bn-link.com
Web: www.bn-link.com
Hours: 9AM - 5PM PST, Mon - Fri
Designed in California, Made in China