

# TABLET FIRMWARE INSTRUCTIONS



# FOLLOW THESE INSTRUCTIONS TO UPDATE YOUR CM-7000 SERIES TABLET:

#### Step 1.

Using the email provided by <u>CO2Meter</u>, click on the "<u>download the file</u>" button to download the CM-7000 series firmware file.

### Step 2.

Once downloaded, Plug an empty flash drive into the computer.

# Step 3.

Go to where you saved the file, named 'v7-multidrop.apk' and move it to the flash drive. \*DO NOT RENAME THE FILE\*

### Step 4.

\*<u>WARNING!</u> Please ensure this file name displays EXACTLY: "<u>v7-multidrop.apk"</u>.

### Step 5.

Next, safely remove/eject the flash drive from your computer.

### Step 6.

Plug the flash drive into the bottom of the <u>tablet</u> in the USB port. The update should begin automatically after a couple of seconds.

### Step 7.

Wait for the update to finish installing (this install should not take more than 1 minute).

# Step 8.

You will see an alert pop up that says "Unfortunately, Multidrop has stopped."

[This is supposed to happen]. Press 'OK' to finish.

# Step 9.

On the tablet screen wait for the firmware to finish updating and press the 'settings' gear in the top right corner.

# Step 10.

Scroll all the way to the bottom of the screen and it should read "Version v2.2.23"

This means your tablet has been updated!



\*PLEASE NOTE\*

FOR PROPER UPDATE YOU MUST FOLLOW BOTH PAGE 1 AND 2 INSTRUCTIONS.

# SENSOR FIRMWARE INSTRUCTIONS



# FOLLOW THESE INSTRUCTIONS TO UPDATE YOUR CM-7000 SERIES SENSORS:

\*Please Note: Depending upon your CM-7000 series configuration, you will need to repeat steps 1-6 for EACH sensor\*

### Step 1.

From the home page of the CM-7005 tablet, press on any of the "sensor circles" to go to the sensor detail page.

### Step 2.

Press on the lock icon in the top right corner and enter the password: 'co2meter' to unlock the sensor settings.

(The settings will remain unlocked for 5 min)

### Step 3.

Press the 'UPDATE SENSOR' button.

# Step 4.

A prompt will come up asking if you are sure you would like to soft reset your sensor.

### Step 5.

Press "YES".

### Step 6.

Press the '**DONE**' button to go back to the home page.

### Step 7.

To verify the update was successful: go into the same "sensor circle" and look to see that the version number (located above the sensor name) has changed to v1.1.7.

### Congratulations!

This means your sensor(s) and tablet have all been updated!

FOR ADDITIONAL SUPPORT CONTACT: SUPPORT2@C02METER.COM