

INSTALLING

The VCP driver is automatically installed by Windows Update for CP210x

Otherwise, unzip the .zip file and you will have a directory containing the driver installer files.

Prompted install

If Windows prompts you to install a driver for a CP210x device

(for example, when you plug the AgriEid scanner into your computer) :

1. Use the dialog to browse for the driver location
2. Locate the driver folder (that you previously unzipped)
3. Follow the instructions

Manual install

1. Using Windows File Explorer, locate the driver folder (that you previously unzipped)
2. Right click on the silabser.inf file and select Install
3. Follow the instructions

UNINSTALLING

1. The device must be plugged in
2. Run Device Manager
3. Locate the device you want to uninstall
4. Right click on the device and choose "uninstall"
5. Follow the instructions