

PIVOT™

Better Connection. Better Protection.
*Making the **Case** for Aviation.*

ATR-X Mount Installation and Removal Manual



Document no. ATR-X Mount Installation and Removal Manual	Revision 20-01	Date 08 Dec 2020	Page 2 (4)
---	-------------------	---------------------	---------------

Read Before Use

Follow the instructions to ensure proper installation, deployment, and maintenance of the PIVOT ATR-X mount (PM-ATR-X). The PM-ATR-X is interchangeable on the Captain and First Officer sides. Use of the PM-ATR-X may require engineering approval prior to installation or removal.

Purpose

Provide information for correct installation, removal, and use of the device for use in aircraft.

Extent

This instruction manual is appropriate for all personnel involved in the installation, removal, or use of the device for use in aircraft.

Reference / Definitions

Device PM-ATR-X



Revision Highlights

Initial publication.

Revision Record

Revision Number	Revision Date	Author	Technical Approval
20-01	08 Dec 2020	Jessica Gillespie Swanwick	Nate Stoffregen

Responsibility

PIVOT reserves the right to make design updates to meet new requirements without obligation to modify existing installations. This manual is subject to change without notice. Service Bulletins may be issued separately and their effect on this manual will be made evident by reissue of the appropriate list of Service Bulletins. This document can only be changed by an authorized PIVOT employee.

Illustrations

Visual depictions are for explanatory purposes only.

Overview

Total installation time for a shipset (CA and FO) is approximately five (5) minutes. The Captain and First Officer devices are the same device with the same installation and removal process. Installation requires the use of a Philips head screwdriver. Accomplishing the steps detailed in the manual provide any user with required data for successful installation and removal. You may also want to refer to the following link: <https://pivotcase.com/ltrm/>.

Installation Instructions

1. Remove the clipboard from the clipboard mount. Retain the original screws.
Note: If any other device is mounted to the clipboard mount on an ATR, removal of the device will be necessary prior to installing the PM-ATR-X.
2. Align the holes on the PM-ATR-X to the holes on the clipboard mount.
3. Using the original screws, attach the PM-ATR-X to the clipboard mount.



Figure 1 PM-ATR-X Installed on First Officer's Side

Attachment & Removal of PIVOT Case to Mount

Refer to PIVOT Case User Guide for details.

Removal Instructions

1. Hold the device with one hand.
2. Remove both screws.
3. The device will separate from the clipboard mount.
4. Retain or reinstall screws as directed by company policy.

Daily Use Considerations

Scratches and other surface imperfections are typical and do not affect the performance of the device.

If a discrepancy is identified, remove the device from service and either repair or replace. If any part is visibly damaged, loose, or missing, remove the device from service and either repair or replace before further use. All surfaces of the device may be wiped with a solvent-free cleaner to remove any accumulated dirt or debris prior to being re-installed.

Additional Information

To learn more, please visit pivotcase.com for instructional videos, product support and additional information about PIVOT products. You'll find valuable online resources to enhance your user experience and see the complete line of PIVOT products.

If you have questions, please contact PIVOT Support.



www.pivotcase.com/support



sales@pivotcase.com



1-888-4-FLYBOYS (1-888-435-9269)
Outside the U.S.A.: 281-895-0128



www.youtube.com/c/pivotcasevideo

PIVOT™
Better Connection. Better Protection.
*Making the **Case** for Aviation.*

TM and © 2019 Fly Boys All rights reserved. Designed in USA. Printed in USA.