

Installation Supplement

Eurotherm 3/4" Thermostatic Cartridge 18.30.147



Lubricate Large Rubber O-Ring

Apply plumber's grease or Vaseline to the large rubber O-ring around the thermostatic cartridge, to help maintain the elasticity of the rubber.

Tighten Screws Evenly

When installing the Cover Screws, tighten each a little at a time, so they evenly tighten the cover plate in place.

Calibrate Thermostatic Cartridge

When replacing the thermostatic cartridge, calibrate the cartridge by setting the hot and cold temperature limits, to protect the user from excessively hot water when bathing.

See Installation Instructions for details.