



Quick Set Up Guide: 15970



Description:

- 1) Main Unit
- 2) Impact device
- 3) Port for impact device
- 4) Impact Coil
- 5) Impact handle
- 6) Release Button
- 7) Calibrated Test Block

Quick set up procedure:

1) PLUG #2 IMPACT DEVICE IN TO PORT #3

- 2) Press the RED button to power unit on. The 15970 will automatically recognize the impact device.
- 3) Grab the #4 Impact Coil with one hand, Grab the #5 impact handle with your other hand and gently squeeze the two halves together and wait for it to "Click". This click is the impact body being loaded. Gently release #4 & #5 and allow it to return to it's original position. Do Not Jam down on this impact device.
- 4) Stand the impact device on the test block as flat and steady as possible.
- 5) Gently push the #6 Release Button to allow the impact body to be released. You will hear the impact ball make contact with the surface of the test block.
- 6) Hardness Value will be displayed on the screen