

UniNet[®]

iColor[®]

PRINTING SOLUTIONS

iColor[®] 1-Step *AquaClear* Media for Hard Surfaces

Part # ICHAC

iColor[®] 1-Step **AquaClear** transfer media is an easy to use, all-in-one transparent media for use on various substrates and hard surfaces such as candles, ceramic, glass, plastic and more! Use this media on hard to reach areas or when applying with a heat press is not possible. The use of an iColor[®] printer in white underprint mode is highly suggested. Regular white toner printers overprint white only, and can only be used if you are transferring to a substrate with a white background since they are not capable of white underprinting. Application to clear or dark surfaces without white underprint will result in dull or washed out images. Please follow the steps below for best results:

1. Place transfer sheet into the appropriate tray of the iColor[®] printer, print side up or down, depending on your model (the glossy side of this media is the print side).
2. Paper type should be 'Heavy' if printing from the iColor[®] 500/600 and 'Coated Glossy' if printing from the iColor[®] 550. Page size should be 'Letter'. **DO NOT** set the job to mirror print.
3. If using the iColor[®] **TransferRIP or ProRIP Software**, add 200% – 300% white underprint if applying to clear or dark surfaces.
3. Print the image.
4. Cut the image out as closely as possible.
5. Dip the image in water for approximately 60 seconds. The paper will roll up; this is normal.
6. Remove from the water and hold the image between your thumb and pointer finger. Move your fingers in an opposite motion to remove the liner slightly from the top of the image.
7. Affix the top of the image to the substrate where the liner was removed. Hold the image on the substrate at the point of contact and slowly pull the liner away in one smooth motion.
8. Align the image on the substrate as desired. Brush it with your finger or a piece of plastic to remove any creases or air bubbles.
9. Use a towel to remove any excess water and let dry for at least three hours.

To see video instructions for iColor[®] AquaClear Media, visit www.icolorprint.com/video

Also available:

iColor® 1-Step **LIGHT** and **SPEED TRANS LIGHT** Transfer Media for light colored garments

iColor® 2-Step **Standard** Transfer Media for light and dark colored garments

iColor® 2-Step **GLITTER** Adhesive Transfer Media (for use with iColor® 2-Step **Standard** Transfer Media)

iColor® 2-Step **Premium** and **Premium STRETCH** Transfer Media for light and dark colored garments

iColor® 2-Step **Presto!** Transfer Media for textiles and hard surfaces

iColor® 1-Step **CLASSIC, Premium, WOOD AND LEATHER** and **CERAMIC** Hard Surface Transfer Media

iColor® 2-Step **Temporary Tattoo** Transfer Media

...and more! Contact your dealer for more information.

August 2018 Revision - A newer version of this manual may be available at www.icolorprint.com/support