Trossbeats



USER MANUAL





App Download

Scan the QR code to download the "FitCloudPro" app

OR

Download "FitCloudPro" App from PlayStore or iOS App Store.



Connection

- Open app and set up your profile
- Click on 'Add Device' and select "CB-DIVA" from the list
- Pairing successful

Buttons and touch controls -

- Press the crown key button to enter the Main Menu
- Rotate the crown key to switch to yourfavourite watch screen
- Press on the crown key to return to the main screen,or double press on the crown key to switch between the menu styles.



Power On

Long press on the rotating crown key for 3 secs to turn on the Smartwatch.

Charging

Connect the back of the watch to the magnetic charger available in the box. Charge the watch completely





Watch Functions

Always On Display

After the watch is connected to the App, you can turn on the Always on display in the settings > Display > AOD Clock > You have 2 options – Analog / Digital Screen for AOD.

Alarm Clock

After the watch is connected to the App, you can set a single alarm, the cycle of the alarm, and also up to 5 alarms in the App terminal.

Stopwatch

Click the start button to start the timing, click the pause button to stop the timing, click the reset button to return the timing to zero.

A maximum of 10 records can be saved.

Breath training

During breath training, there are 2 options – 1 & 2 mins.

Users click on the corresponding time to perform breath training. After click Start, follow the icon in breath training to zoom in and breath in, zoom out and breath out.

Blood Pressure

When entering the blood pressure measurement interface, the green light at the bottom will start the test and there will be a vibration reminder, when the measurement is completed within 30 to 60 seconds. The measurement is based on PPG technology.

Women's health

After the watch is connected to the app, Women's health alert can be enabled on the app to view the information on the watch.

Heart Rate

When you enter the heart rate measurement interface, the green light at the bottom will start to measure. When the measurement is completed in about 40 seconds, there will be a vibration reminder. If the message "Please wear the watch correctly" is displayed, you need to wear the watch again.

Blood Oxygen

When entering the blood oxygen measurement interface, the red light at the bottom will start the test for 30 to 60 seconds and there will be a vibration reminder when the measurement is completed. The measurement is based on the PPG technology.

Weather Forecast

After the watch is connected to the app, this weather interface will display the real-time weather temperature and the weather for the next three days

Messages

After the watch is connected to the app, open the push of relevant information on the app side, the watch side can receive the corresponding push message, and up to 15 recent messages can be saved.

Setting

The settings function includes the screen display (switch dial, duration of light, brightness adjustment, duration of wrist flip), language, sound & vibration, menu style, battery, password, QR code, system and time settings.

Music

When the watch is connected to the app, you can control the pause and start of the mobile music player, adjust the volume and switch songs.

Timer

In the timing function, the system preset the common timing duration. You can click the corresponding duration to time quickly or click the custom button to set the time. Click the Start button to start the timing, click the pause button to pause the timing, Click the reset button time reset.

Sleep

The watch displays total sleep duration as well as light and deep sleep duration of the previous night, and the sleep screen slides up to show sleep data generated in the last seven days.

Calculator

On the menu screen, click Calculator to enter the function screen of Calculator. On this screen, you can do basic calculations like addition, subtraction,multiplication and division.


Find my Phone

After the watch is connected to the app, click to find the phone, the phone will ring and the watch will show that the search is successful. If the watch and the app is not connected, watch side will prompt Bluetooth disconnect.

Control Center

Features: Brightness adjustment, settings, find phone, system information, vibration intensity, audio Bluetooth, do not disturb mode, power saving mode.

Яскозявеатя



support@crossbeats.com