
truweigh 0



Thanks for purchasing the NOTE Digital Mini Scale! This User Guide is designed to get you up and running quickly with your scale. Scales are precision instruments and require proper care and skill to get the best results. If you have questions or need support, visit us at http://www.truweigh.com/support or scan the QR Code on the back of this manual using your smartphone.




ON/OFF - Turns the scale ON or OFF.

MODE - Changes the weighing unit.

TARE - Zero's the scale. Also subtracts the weight of an empty container (see Tare Function).

PCS - Enters Counting Mode (see Counting Function)



Weighing Your First Item

- Press the **ON/OFF** key to turn the scale on.
- Place the item on the center of the weighing platform.
- Take your reading from the display. You can press the MODE key to convert between weighing units.





- 1. Place a sample quantity of 25, 50, 75 or 100 pcs of the item you want to count on the platform.
- Press and hold the PCS key to enter counting setup.
- Tap the **MODE** key to select your sample quantity.
- Press the PCS key to confirm the sample qty and set the average piece weight (APW) in memory.
- You may now place any quantity on the scale and view the piece count. ('pcs' will show on the display)

Things To Avoid



Unlevel Surfaces



Air Currents



Radio Frequency Interference



Vibration



High Humidity



Extreme Temps

Tare Function

The Tare function allows you to subtract the weight of a container so that the display only shows the weight of the contents.



Place an empty tray or container on the platform.

Press the TARE key to subtract the container's weight.

Add items to the container to see their weight on the display.



NOTE: The weight of the container will subtract from ! the available capacity and will leave a negative value on the display once the weight is removed. Press **TARE** again to return the display to zero.

Auto-Off

By default, the scale will auto-off after 180 seconds of inactivity. To change or disable the auto-off timer:

- Turn the scale off. 1.
- 2. Press and hold the **MODE** key and simultaneously press the **ON/OFF** key 4~5 times quickly.
- The display will show the current Auto-Off setting. 3. Press the **MODE** key to change the setting between 180 sec, 120 sec, 60 sec, or 0 sec (auto-off disabled).
- 4 Press **ON/OFF** to turn the scale off when finished.

Accuracy

Your scale comes calibrated from the factory and most users wont need to calibrate their scale for a long time. You should check your scale's accuracy periodically using calibration weights and perform calibration if necessary. **NOTE:** Only use trusted calibration weights.

Calibration



Calibration is permanent and should only be performed using accurate calibration weights that match the requirements for your scale. Do not use coins or other household items to calibrate.

- 1. Prepare the required weight for your scale. (see chart on back)
- 2. Find a flat and level surface to perform calibration and let the scale adjust to room temperature.
- Press ON/OFF to turn the scale on and wait for the scale to stabilize.
- Press and hold the MODE key until the display shows 'CAI'.
- Make sure nothing is on the platform then press MODE to confirm the zero point.
- The display will then flash the required calibration weight.
- 7. Place the required calibration weight on the center of the platform.
- The display will show 'PASS' then return to normal weighing mode. You may now turn the scale off or continue weighing.



Specifications

NO		

Max Capacity 100 g / 3.527 oz / 3.215 ozt/ 64.30 dwt / 500.00

ct / 1543.2 gn

Readability 0.01 g / 0.001 oz / 0.001 ozt / 0.01 dwt / 0.05 ct

/ 0.2 gn

Weighing Units

g, oz, ozt, dwt, ct, gn

Overall: 3.0 in x 3.3 in 0.6 in Platform: 1.9 in x 2.7 in

Platform: 1.9 in x 2.7 in Display: 0.4 in x 0.9 in

Calibration Weight

100g

Power 1 x CR2032 Batteries

Warranty 10 Year Limited Warranty

For more information, including weighing tips and support, scan this code with your smartphone

Or visit us online at truweigh.com/support/

