

Lilitab designs its products to withstand the regular cleanings needed to meet the healthcare industry's strict infection control requirements.

Providing patients with a safe environment for their care and recovery requires a commitment to hand hygiene and the proper cleaning of the equipment used by the staff. Below we outline how to safely clean Lilitab enclosures, mounts and docking cradles.

Let's get cleaning.

Please follow your organization's infection-control policies and the disinfectant chemical manufacturer's instructions to determine the frequency and duration with which the following cleaning procedure should be performed.

1. Lock the head unit into the mount to prevent excess liquid from entering the device.
2. Apply an approved cleaning product to a sterile cloth or use the wipes provided.
3. Wipe all surfaces of the Lilitab device for the time required by the product. Avoid pooling liquid on any part of the device and dry immediately with a sterile cloth. Use a cotton-tipped swab to reach any recessed areas.
4. If the tablet screen has streaks, lightly moisten a lint-free cloth with an approved cleaner recommended by your tablet manufacturer.



Approved cleaning products

- Sani-Cloth® HB
- Sani-Cloth Plus
- Sani-Cloth Bleach
- Super Sani-Cloth
- CaviWipes™
- Virex® 256
- Windex® Blue
- Clorox® Bleach-10%
- 409® Glass and Surface Cleaner
- Isopropyl Alcohol Wipes (70%)
- Gentle dish soap and water

A note of caution. Repeated use of non-approved chemical cleansers may cause discoloration or swelling. We highly recommend only using the above approved products on your Lilitab.