

# Easi-Speak® Docking Station

Charge up to 6 Easi-Speaks



User Guide www.tts-group.co.uk



### **Important Information**

- Do not allow your Easi-Speak Docking Station to come into contact with water or other liquids.
- Warranty is void if the case is opened for any reason.
- The warranty does not cover any data loss from the unit nor any consequential loss of information.

### **FCC** compliance

### Note:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the the user authority to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Easi-Speak® Docking Station

### **Know Your Product**



The Easi-Speak docking station is supplied with a multi-region adaptor. The adaptor is supplied with the UK plug fitted but you can change this easily to suit any country. Press the release button and slide the UK plug out and replace with the required plug module. Slide the plug module in until it 'clicks' in place securely.



The safety isolating transformer to be used with the Docking Station should be regularly examined for potential hazards such as damage to the cable, cord, plug, enclosure or other parts. In the event of any damage, the Docking Station must not be used until any damage has been properly repaired.

The Docking Station is not intended for children under 3 years old.

The transformer is not a toy.



# Easi-Speak® Docking Station

## **Specifications**

Specification	
Input Voltage	100 - 240V a.c.
Frequency	50 - 60 Hz
Standby Power	0.3W (Max)
Output Voltage	5V d.c. ± 5%
Output Current	1500mA (Max)
Output Power	7.5W

## **Trouble Shooting**

Problem	Solution
Power LED does not light	Check that the mains adaptor is connected and the mains outlet is switched on
The Easi-Speaks do not charge	Ensure that the power LED is on and that all Easi-Speaks are switched off whilst charging



### **Technical Support**

Please visit www.tts-group.co.uk for the latest product information.

Email feedback@tts-group.co.uk for technical support.

TTS Group Ltd.
Park Lane Business Park
Kirkby-in-Ashfield
Nottinghamshire
NG17 9GU UK

Freephone: 0800 318686 Freefax: 0800 137525

**WARNING:** Do not dispose of this product in household waste.

**WARNING:** Hand it over to a collection point for recycling electronic appliances. **WARNING:** Not suitable for children under 36 months due to small parts –

choking hazard.

Made in China, on behalf of TTS Group Ltd.

TTS Product Code:

IT10108

