



## Compu-Dobby® 4.5 (CD4.5) Firmware Update Procedure

### For Windows:

1. Download the appropriate firmware file from the AVL website at:  
<https://avllooms.com/apps/help-center#hc-firmware-for-compu-dobby-45-little-weaver-10>
2. Download and install **AVLUtilities** (this installs both the AVLUpdate and the AVLAdmin apps) from the AVL website at:  
<https://avllooms.com/collections/software/products/avl-drive-loom-control-software-for-cd-4-or-later>
3. Turn on the CD4.5
4. Connect the USB cable from the CD4.5 to the computer
5. Open the **AVLUpdate** app
  - a. A progress window and a file selection window should appear
  - b. Select the downloaded firmware file, click Open
6. The file will start uploading to the CD4.5.
  - a. The progress window may say 100%, but you need to wait until you see the “update was successful” message before closing AVLUpdate (may take about 1 minute).

