

BREAK DOWN - Here are step-by-step instructions for breaking down the Venture Pro:

Use this picture of a fully assembled lift for reference.



Adjustable Leg Supports: fold in the Adjustable Leg Supports, then remove the Upper Fully Adjustable Platform from the Bent Arm.



Upper Bent Arm: Remove the Bent Arm from the bottom assembly.



Remove the Crossbar: Remove the Locking Pins and Locking Knob (fig 9) to release the Crossbar, then slide the Crossbar off the lift. Be sure to pull the Green Cable while removing the Crossbar to be sure it doesn't get stuck.



Remove the Bearing Post: Remove the two securing bolts, then remove the Bearing Post (NOTE: the Bearing Post will be exposed after the Crossbar has been removed)



Foot Pedal Assembly: Once the Bearing Post is removed, fold the Legs and Foot Pedal assembly into the base.

The following two pictures depict 1) the Legs and Foot Pedal Assembly folded in and the Bearing Post next to it and 2) the Bearing Post stored on the folded Foot Pedal Assembly.





Feel free to contact us with any further questions or concerns you get into the assembly and use of the lift. Our helpful techs are available Monday-Thursday 8:30 am - 4:00 pm and Friday 8:30 am - 3:30 pm.

Thank you,
TopLift Pros Team
321-425-4336