



Milkplan Bulk Tank: Quick Reference Guide

1. How to See the Set Point

The Set Point of your tank is the temperature at which the compressor will activate.

To see the Set Point:

- Press and immediately release the SET button. The Set temperature will be displayed.
- Wait for 3 seconds for the probe value to be displayed again,

2. How to Change the Set Point

The tank's compressor shuts off when the fluid temperature reaches the Set Point.

To change the set point on your tank:

- Hold the SET button for 3 seconds.
- The °F symbol will flash.
- Use the ↑ ↓ buttons to adjust the Set Point to the desired temperature.
- Press the SET button again to exit.

3. How to Change the Hy Point

The compressor turns on when the fluid temperature rises about the Set Point + the Hy Point. Example: The Set Point is 38°F and the Hy Point is 3°F (the default setting for your tank). As $38^{\circ}\text{F} + 3^{\circ}\text{F} = 41^{\circ}\text{F}$, the compressor will turn on when the fluid temperature rises above 41°F.

To change the Hy Point on your tank:

- Hold the SET and ↑ ↓ buttons for 7 seconds simultaneously.
- The Hy symbol will appear.
- Press the SET button again.
- The Hy Point will be showing (default value is 3°F).
- Change the Hy Point using the ↑ ↓ buttons to the desired value.
- Press the SET button again to exit.
- Do not press any buttons again for 15 seconds and the active fluid temperature will be displayed again.

4. How to Start a Manual Agitation Cycle

The agitator on your bulk tank will operate any time the compressor is running and for 3 min. cycles with 15 min. pauses (these intervals are adjustable). You may want to start the agitator between intervals to take a sample.

To start a Manual Agitation Cycle:

- Press and hold ↻ button to make the agitator operate.
- It will run for 3 minutes and shut-off.