

SHS200A - Operating Hours & Spray Interval Operating from 9am to 10pm Daily - Spray 30s Pause 95s

Ensure that the time on the nebulizer matches the local time before configuring any events.

Should the time differ, kindly follow the steps provided below to adjust the local time:

Local Time Settings (Example: Current day and time is Tuesday, 10.35am)

Press SET once, you will see the hours blinking

Press **UP** or **Down** to adjust

Press **SET** again, you will see the Mins blinking

Press **UP** or **Down** to adjust

Press SET again, you will see the Day of the Week blinking

Press **UP** or Down to adjust to the Day of the week

Press SET again to save and exit

Setup to Operate Daily from 9am to 10pm, Spray 30sec and Pause 95sec

Press Mode once, you will see the start hours blinking

Press **UP** or **Down** to adjust to **9** (9am meaning 0900 hrs)

Press Set once, you will see the start min blinking

Press **UP** or **Down** to adjust to **00** (9am meaning 0900 hrs)

Press **Set** once, you will see the start Days blinking (*Small Dot under each Day*)

Press **UP** or **Down** to adjust to All Dots below the Day appear (*Meaning Everyday*)

Press Mode again, you will see the end hours blinking

Press UP or Down to adjust to 22 (10pm meaning 2200hrs)

Press Set once, you will see the end min blinking

Press **UP** or **Down** to adjust to **00** (10pm meaning 2200hrs)

Press **Mode** once, you will see a 2 digit number blinking

Press **UP** or **Down** to adjust to **30** (*Indicating to spray for a duration of 30 seconds*)

Press Mode again, you will see a 2 digit number blinking

Press **UP** or **Down** to adjust to **95** (*Indicating a pause for a duration of 95 seconds*)

Press Mode 4 times to Save and Exit

Special Note:

- Please make sure that there are no timing overlaps as it can impact the operation. The event time follows a 24-hour format from 00:00 to 23:59.
- If you wish to schedule an event from 10 PM to 2 AM, create Events as follows:
 Event 1 from 22:00 to 23:59
 Event 2 from 00:00 to 02:00