



SHTM500 - 1 Event Setup

Operating from 9am to 10pm Daily - Spray 20s Pause 60s

Ensure that the time on the nebulizer matches the local time before configuring any events.

Should the time differ, kindly follow the steps provided below to adjust the local time:

Local Time Settings (Example: Current day and time is Tuesday, 10.35am)

Press **SET** once

00:00 (The hour will be blinking)

Press **Up/Down** to set to 10

Press **SET** to change to min setting

00:00 (The min will be blinking)

Press **Up/Down** to set to 35

Press **SET** to set the day of the week

Press **Up/Down** to set to 2 (Tuesday)

Press **Mode** to Save and Exit

Event Setup

Press **Mode** once

00:00 (The hour will be blinking)

Press **Up/Down** to set to 09

Press **SET** to change to min setting

00:00 (The min will be blinking)

Press **Up/Down** to set to 00

Press **SET** to change to Days to operate

You will see 1234567 blinking, Press **Up/Down** till you see 1234567

Press **Mode** once to set the OFF timing

00:00 (The OFF hour will be blinking)

Press **Up/Down** to set to 22

Press **SET** to change to min setting

00:00 (The min will be blinking)

Press **Up/Down** to set to 00

Press **Mode** once to set the Event 1 work duration

Press **Up/Down** to set to 20 (Meaning Spray 20s)

Press **Mode** once to set the Event 1 pause duration

Press **Up/Down** to set to 60 (Meaning Pause 60s)

Press **Mode** once to go to Event 2 (Ensure it show 00-00 (Meaning Event 2 not used)

Press **Mode** once to go to Event 3 (Ensure it show 00-00 (Meaning Event 3 not used)

Press **Mode** once to go to Event 4 (Ensure it show 00-00 (Meaning Event 4 not used)

Press **Mode** once to go to Event 5 (Ensure it show 00-00 (Meaning Event 5 not used)

Last Press **Mode** once to save all setting

Setup completed

Special Note:

- **Please make sure that there are no timing overlaps as it can impact the operation. The event time follows a 24-hour format from 00:00 to 23:59.**
- **If you wish to schedule an event from 10 PM to 2 AM, create Events as follows:**
 - Event 1 from 22:00 to 23:59**
 - Event 2 from 00:00 to 02:00**