



SHTM500 - 2 Event Setup

Event 1: Operating from 8am to 8pm Monday to Friday Spray 10s Pause 200s

Event 2: Operating from 5pm to 8pm Saturday Spray 10s Pause 200s

Ensure that the time on the nebulizer matches the local time before configuring any events.

Should the time differ, kindly follow the steps provided below to adjust the local time:

Local Time Settings (Example: Current day and time is Tuesday, 10.35am)

Press **SET** once

00:00 (The hour will be blinking)

Press **Up/Down** to set to 10

Press **SET** to change to min setting

00:00 (The min will be blinking)

Press **Up/Down** to set to 35

Press **SET** to set the day of the week

Press **Up/Down** to set to 2 (Tuesday)

Press **Mode** to Save and Exit

Event Setup

Press **Mode** once to set the [Event 1 ON Timing](#)

00:00 (The hour will be blinking)

Press **Up/Down** to set to 08

Press **SET** to change to min setting

00:00 (The min will be blinking)

Press **Up/Down** to set to 00

Press **SET** to change the [Event 1 Operating Days](#)

You will see 1234567 blinking, Press **Up/Down** till you see 12345

Press **Mode** once to set the [Event 1 OFF Timing](#)

00:00 (The OFF hour will be blinking)

Press **Up/Down** to set to 20

Press **SET** to change to min setting

00:00 (The min will be blinking)

Press **Up/Down** to set to 00

Press **Mode** once to set the [Event 1 work duration](#)

Press **Up/Down** to set to 10 (Meaning Spray 10s)
Press **Mode** once to set the Event 1 pause duration
Press **Up/Down** to set to 200 (Meaning Pause 200s)

Press **Mode** once to set the **Event 2 ON Timing**
Press **SET** to set Event 2 timing (Repeat the steps for Event 1)
00:00 (The hour will be blinking)
Press **Up/Down** to set to 17
Press **SET** to change to min setting
00:00 (The min will be blinking)
Press **Up/Down** to set to 00

Press **SET** to change the **Event 2 Operating Days**
You will see 1234567 blinking, Press **Up/Down** till you see 6 (Saturday)

Press **Mode** once to set the **Event 2 OFF Timing**
00:00 (The OFF hour will be blinking)
Press **Up/Down** to set to 20
Press **SET** to change to min setting
00:00 (The min will be blinking)
Press **Up/Down** to set to 00
Press **Mode** once to set the **Event 2 work duration**
Press **Up/Down** to set to 10 (Meaning Spray 10s)
Press **Mode** once to set the Event 1 pause duration
Press **Up/Down** to set to 200 (Meaning Pause 200s)

Press **Mode** once to go to Event 3 (Ensure it show 00-00 (Meaning Event 3 not used)
Press **Mode** once to go to Event 4 (Ensure it show 00-00 (Meaning Event 4 not used)
Press **Mode** once to go to Event 5 (Ensure it show 00-00 (Meaning Event 5 not used)

Last Press **Mode** once to save all setting
Setup completed

Special Note:

- **Please make sure that there are no timing overlaps as it can impact the operation. The event time follows a 24-hour format from 00:00 to 23:59.**
- **If you wish to schedule an event from 10 PM to 2 AM, create Events as follows:**
 - Event 1 from 22:00 to 23:59**
 - Event 2 from 00:00 to 02:00**