

Dear. All customers

inform to all our Customers that we have new update in software.

What's new (version 2.1)

Enhanced Jewellery and Loose Detection.

Common CVDs now show with red markings together with HPHT stones in Jewellery Detection Mode.

How to update

Step 1 Go to Menu Settings.

BLE H/W Conne	ection	
Wi-Fi Connectio	n	٠
Check for upda	tes	
Lamp's Life-tim	e(sec)	2456943
Storage Space		42 GB/52 GB
User's Manual		
Customer Supp	ort	
TeamViewer Su	ipport	
Reset Lamp's Life	-time (sec)	
8	Version 2.0	
	0	<

Step 2 Click Wi-Fi Connection to have an internet connection.

			ocuron
Con	nected network		
Ŷ	"smartpro2"		
Avai	lable networks		
Ŷ	SETUP		
Ŷ	smartpro2		
Ŷ	walcom01		
Ŷ	CLASS4		
Ŷ	LevelOne		
Ŷ	DIRECT-5D-HP DeskJet 3700 series		
Ŷ	KPG2012 2.4G		
Ŷ	DIRECT-jL83-G	4010series	
Ŷ	Class_4.1		
Ŷ	VIP_2.4G		
Ŷ	CLASS3NEW_I	оТ	
Ŷ	Ougero_2.4G		
		0	1

Step 3 Go back to Menu Settings then click "Check for updates"

< Settings		
BLE H/W Con	nection	
Wi-Fi Connec	tion	
Check for upo	lates	
Lamp's Life-ti	me(sec)	2456943
Storage Spac	e	42 GB/52 GE
User's Manua	I	
Customer Su	oport	
TeamViewer	Support	
Reset Lamp's L	ife-time (sec)	
	S/N : SPAU-999999 Version 2.0	
	0	/

Step 4 Download the new Software Version.



Step 5 Click Install after finished downloading.

