






# Installation guide for Service tool

Requirement Windows 7, 10


1. Download\_ServiceTool and package at: [www.3M.com/peltorhub](http://www.3M.com/peltorhub)
2. Unpack the Zip:ed ServiceTool file and install it.
3. Fill in the form.
4. Send a request for a license key.
5. When you get the license key, copy it to the tab.
6. The tool will start up.
7. Choose folder where you want the files to be placed.
8. Go to the maintenance folder 1



9. Point at the 2 "Add package from Zip file"



10. Choose the right package and press the open button. (remember the place where it is downloaded)
11. You will receive confirmation that the package was successfully installed.
12. Now the ServiceTool is ready to use.




13. Choose Hid dongle or Com port if you use PPN: 19-0009\* cable at 3 (lower row) \*Driver required
14. Try to connect to the device at 4



15. Row will go green and you can see that you are connected (5)

16. Device will be presented (6)



17. Read the headset by pressing this button (7).

18. The maintenance tab will indicate with red digits that software update is available (8).

**3M PELTOR Service Tool**

Configuration Maintenance<sup>12</sup> Advanced Reports Settings

MT73H7A4D10EU x

CONFIGURATION

- Automatic Power Off
- Bluetooth
- Two Way Radio
- Product Information**
- Situational Awareness
- Speech Microphone
- Supply

Configuration Version	cfg-MT73H7A4D10EU-release-1.3
Hardware Serial Number	17220659
Hardware Version	
Model Number	MT73H7A4D10EU
Product Serial Number	
Software Version	sw-k385-st-release-1.3

**3M PELTOR Service Tool**

Configuration Maintenance<sup>12</sup> Advanced Reports Settings

MT73H7A4D10EU

✓ 1.4.7

**MT73H7A4D10EU**

**Version:** 1.4.7

**Date installed**  
2019-10-23 09:38

**Description**  
WS LiteCom Pro III MT73H7A4D10EU

**Dependencies**  
k385-language-english-heather.1.7.5, k385-language-spanish-rosa.1.7.5, k385-language-french-louise.1.7.5, k385-language-german-sarah.1.7.5, k385-language-empty-empty.1.7.5, k385-st-application.1.4.4, k385-st-bootloader.1.5.0, sw-k385-csr.1.2.0

**ReleaseNotes**

**Scripts**

**Install**

**Reset** ▶


**Status** ▶

9


10

11

19. To update the device go to the maintenance folder (9)
20. Check software version (10)
21. Press install button (11)



22. Confirm by pressing "OK"



23. Choose "Default" if you want all 4 language to be installed.
24. Choose "Custom" if you want to customize the languages.

## Information

Please choose if you want the installation to preserve the current configuration or reset it to factory default.

Preserve

Reset

Cancel

25. Press "Preserve" if you want the previous customized configuration to be installed after software upgrade.

26. Choose "reset" if you want the headset to be as first delivery without customized configuration.

The screenshot shows the 'Install' window with a 'Summary' section and a 'Progress' section. The 'Summary' section displays 'Total time: 00:21:45.8' and 'Result: Success'. The 'Progress' section lists 17 steps, all marked with a green checkmark. Two red arrows point from the '12' and '13' markers to the 'Result: Success' text. The 'Cleanup' step is highlighted in yellow.

Step	Status	Description
17(17)	✓	Prepare installation
4(4)	✓	Confirm installation
3(3)	✓	Select languages
2(2)	✓	Backup parameters
2(2)	✓	Download application
2(2)	✓	Restore production parameters
2(2)	✓	Download first language
2(2)	✓	Download second language
2(2)	✓	Download third language
2(2)	✓	Download fourth language
2(2)	✓	Download Bluetooth application
2(2)	✓	Reset product
2(2)	✓	Restore configuration parameters
3(3)	✓	Finalize installation
1(1)	✓	Cleanup

Approximately the update of the software can be between 20 minutes to 1 hr. for a fully update.