



How to Guide – HE-50 “Quick Start”

(If you have any difficulties during this process - please contact Graintec Scientific on 1300 640 299.)

- STEP 1** Prepare the sample:
(Refer to document “Sample Preparation” for more detail).
- STEP 2** Fill the supplied 9ml “measurer” to the top.
- STEP 3** Empty the contents from the measurer evenly on to the bottom of the measuring cell.
- STEP 4** Place the top measuring unit on the measuring cell.
- STEP 5** Using your hands, screw the top down until the stops meet (i.e. as far as it goes).
- STEP 6** Place the measuring cell in the holder with the handle pointing to the right. The bolts and the hole in the handle act as a guide.
- STEP 7** Select the appropriate product using the rotary switch – e.g. wheat.
- STEP 8** Press the blue “measure” button. This action switches on the HE-50 and commences the measurement.
- STEP 9** In less than 10 seconds, the moisture percentage result will be displayed.
- STEP 10** Note the result according to your procedure.
- STEP 11** Clean the instrument. Open the measuring cell. Using the supplied brushes, clean out the cell and the top unit.