



How to Guide – HE-LITE “Quick Start”

(If you have any difficulties during this process - please contact Graintec Scientific on (07) 4638 7677).

- STEP 1** Prepare the sample:
(Refer to document “Sample Preparation” for more detail).
- STEP 2** Fill the supplied 11ml “measurer” (located on the top measuring cell) to the top.
- STEP 3** Empty the contents from the measurer evenly on to the bottom of the measuring cell.
- STEP 4** Place the top measuring unit on the measuring cell.
- STEP 5** Using your hands, screw the top down until the stops meet (i.e. as far as it goes).
- STEP 6** Press the “On” button
- STEP 7** Select the appropriate product using the up and/or down arrows. Press the “On” button to select your product.
- STEP 8** Press the “On” button. This action commences the measurement.
- STEP 9** In less than 10 seconds, the moisture percentage result will be displayed.
- STEP 10** Note the result according to your procedure.
- STEP 11** Clean the instrument. Open the measuring cell. Using the supplied brushes, clean out the cell and the top unit.