

550B 3058357

Digital Thermometer

To use the 550B, remove the protective sheath, press the ON/DH (Data Hold) button and insert at least 1/2" of the stem into the testing area. Push the ON/DH button a second time and the temperature reading will automatically be held on the LCD display. "°F" will blink when DH is in operation. Pressing the ON/DH button a third time will return the 550B to normal operation. To save battery life, the 550B will automatically turn off after approximately 35 minutes.

Note: When turning the 550B on, the LCD will display the last reading before turning off for 2 seconds. Then it will display the current temperature.

Specifications:

Temperature Range.....	-40° to 550°F
Resolution.....	0.1°F
Accuracy.....	± 1%
Sampling Time.....	1.0 seconds
Battery.....	1.5V Button

(Part No. AB13, SR44)

ARB300

Protective Rubber Boot

Slide the ARB300 onto the thermometer for ruggedized protection and water resistance. Remove boot to clean thermometer.



 **COMARK**
A Fluke Company

Comark Instruments
P.O. Box 9090
Everett, WA 98206, USA
Tel: (503) 643 5204
Fax: (503) 644 5859
Email: sales@comarkUSA.com
www.comarkUSA.com

Made in Korea